

FRU List

Table 6-4. FRU List

CATEGORY	Acer Description	AcerPN
BOARD		
	IO BOARD	55.A6MN2.001
	IO BOARD FOR DIS	55.ADBN2.001
CABLE		
	FFC CABLE FOR IO BOARD	50.A6MN2.001
	FFC CABLE FOR HDD	50.A9BN2.001
	FFC CABLE FOR TP	50.A6MN2.002
	FFC CABLE FOR FP	50.A6MN2.003
	ANTENNA - MAIN	50.A6MN2.004
	ANTENNA - AUX	50.A6MN2.005
	LCD EDP CABLE	50.A6MN2.006
	POWER CORD 1M BLACK SOUTH AFRICA - NEW	27.HEEN2.001
	POWER CORD 1M BLACK BLACK AUSTRALIA	27.Q28N2.002
	POWER CORD 1M BLACK EU	27.Q28N2.003
	POWER CORD 1M BLACK EU(New source)	27.Q7DN2.001

CATEGORY	Acer Description	AcerPN
	POWER CORD 1M BLACK DENMARK	27.Q28N2.004
	POWER CORD 1M BLACK ISRAEL	27.Q28N2.005
	POWER CORD 1M BLACK ITALIAN	27.Q28N2.006
	POWER CORD 1M BLACK JAPAN	27.Q28N2.007
	POWER CORD 1M BLACK CHINA - NEW	27.HEEN2.002
	POWER CORD 1M BLACK INDIA	27.Q28N2.009
	POWER CORD 1M BLACK SWISS	27.Q28N2.010
	POWER CORD 1M BLACK UK	27.Q28N2.011
	POWER CORD 1M BLACK UK(New source)	27.Q7DN2.002
	POWER CORD 1M BLACK TWN	27.Q28N2.012
	POWER CORD 1M BLACK ARGENTINA - NEW	27.HEEN2.003
	POWER CORD 1M BLACK KOREA	27.Q28N2.014
	POWER CORD 1M BLACK US	27.Q28N2.015
	POWER CORD 1M BLACK US(New source)	27.Q7DN2.003
	POWER CORD 1M BLACK BRAZIL	27.Q28N2.016
CASE/COVER/BACKET ASSEMBLY		
	LOWER CASE ASSY - BLACK	60.A6MN2.001
	HDD BRACKET	33.A6MN2.001
	LCD COVER ASSY - SILVER	60.A6MN2.002
	LCD COVER ASSY - BLUE	60.A9BN2.001
	LCD BEZEL BLACK FOR DUAL	60.A6MN2.004

CATEGORY	Acer Description	AcerPN
	LCD HINGE L	33.A6MN2.002
	LCD HINGE R	33.A6MN2.003
	LCD HINGE BRACKET L W/ADHESIVE	33.A6MN2.004
	LCD HINGE BRACKET R W/ADHESIVE	33.A6MN2.005
FAN		
	FAN	23.A6MN2.001
HEATSINK		
	THERMAL MODULE UMA W/O FAN	24.AE0N2.001
	THERMAL MODULE DIS W/O FAN	24.AG0N2.001
KB ASSEMBLY		
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black US International acer Font, Power icon, Media key, V0,NK.I1513.119, NK.I151S.0AT, NK.I1517.0EY)	6B.A6MN2.001
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Greek acer Font, Power icon, Media key, V0,NK.I1513.113,NK.I151S.0AM,NK.I1517.0ES)	6B.A6MN2.002
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Arabic acer Font, Power icon, Media key, V0,NK.I1513.111,NK.I151S.0AK,NK.I1517.0EQ)	6B.A6MN2.003

CATEGORY	Acer Description	AcerPN
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Traditional Chinese acer Font, Power icon, Media key, V0,NK.I1513.112,NK.I151S.0AL,NK.I1517.0ER)	6B.A6MN2.004
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Russian acer Font, Power icon, Media key, V0,NK.I1513.115,NK.I151S.0AP,NK.I1517.0EU)	6B.A6MN2.005
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black US International w/ Hebrew acer Font, Power icon, Media key, V0,NK.I1513.11A, NK.I151S.0AU, NK.I1517.0EZ)	6B.A6MN2.006
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Thailand acer Font, Power icon, Media key, V0,NK.I1513.118,NK.I151S.0AS,NK.I1517.0EX)	6B.A6MN2.007
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Korean acer Font, Power icon, Media key, V0,NK.I1513.114,NK.I151S.0AN,NK.I1517.0ET)	6B.A6MN2.008
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Ukrainian acer Font, Power icon, Media key, V0,NK.I1513.116,NK.I151S.0AQ,NK.I1517.0EV)	6B.A6MN2.009
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Persian acer Font, Power icon, Media key, V0,NK.I1513.117,NK.I151S.0AR,NK.I1517.0EW)	6B.A6MN2.010
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black US International w/ Canadian French acer Font, Power icon, Media key, V0,NK.I1513.11B, NK.I151S.0AV, NK.I1517.0F0)	6B.A6MN2.011
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black US International w/ Bulgaria acer Font, Power icon, Media key, V0,NK.I1513.11C, NK.I151S.0AW, NK.I1517.0F1)	6B.A6MN2.012
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black UK acer Font, Power icon, Media key, V0,NK.I1513.11X,NK.I151S.0BF,NK.I1517.0FL)	6B.A6MN2.013

CATEGORY	Acer Description	AcerPN
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black German acer Font, Power icon, Media key, V0,NK.I1513.11L,NK.I151S.0B4,NK.I1517.0F9)	6B.A6MN2.014
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Swiss/G acer Font, Power icon, Media key, V0,NK.I1513.11V,NK.I151S.0BD,NK.I1517.0FJ)	6B.A6MN2.015
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Belgium acer Font, Power icon, Media key, V0,NK.I1513.11E,NK.I151S.0AY,NK.I1517.0F3)	6B.A6MN2.016
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Danish acer Font, Power icon, Media key, V0,NK.I1513.11H,NK.I151S.0B1,NK.I1517.0F6)	6B.A6MN2.017
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Italian acer Font, Power icon, Media key, V0,NK.I1513.11N,NK.I151S.0B6,NK.I1517.0FB)	6B.A6MN2.018
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black French acer Font, Power icon, Media key, V0,NK.I1513.11K,NK.I151S.0B3,NK.I1517.0F8)	6B.A6MN2.019
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Hungarian acer Font, Power icon, Media key, V0,NK.I1513.11M, NK.I151S.0B5, NK.I1517.0FA)	6B.A6MN2.020
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Norwegian acer Font, Power icon, Media key, V0,NK.I1513.11Q, NK.I151S.0B8, NK.I1517.0FD)	6B.A6MN2.021
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Portuguese acer Font, Power icon, Media key, V0,NK.I1513.11R, NK.I151S.0B9, NK.I1517.0FE)	6B.A6MN2.022
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Spanish acer Font, Power icon, Media key, V0,NK.I1513.11T,NK.I151S.0BB,NK.I1517.0FG)	6B.A6MN2.023

CATEGORY	Acer Description	AcerPN
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Turkish acer Font, Power icon, Media key, V0,NK.I1513.11W,NK.I151S.0BE,NK.I1517.0FK)	6B.A6MN2.024
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Sweden acer Font, Power icon, Media key, V0,NK.I1513.11U,NK.I151S.0BC,NK.I1517.0FH)	6B.A6MN2.025
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black FR/Arabic acer Font, Power icon, Media key, V0,NK.I1513.11J,NK.I151S.0B2,NK.I1517.0F7)	6B.A6MN2.026
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Nordic acer Font, Power icon, Media key, V0,NK.I1513.11P,NK.I151S.0B7,NK.I1517.0FC)	6B.A6MN2.027
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black SLO/CRO acer Font, Power icon, Media key, V0,NK.I1513.11S,NK.I151S.0BA,NK.I1517.0FF)	6B.A6MN2.028
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black CZ/SK acer Font, Power icon, Media key, V0,NK.I1513.11G,NK.I151S.0B0,NK.I1517.0F5)	6B.A6MN2.029
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Brazilian Portuguese acer Font, Power icon, Media key, V0,NK.I1513.11F, NK.I151S.0AZ, NK.I1517.0F4)	6B.A6MN2.030
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black ALA-Spanish acer Font, Power icon, Media key, V0,NK.I1513.11D, NK.I151S.0AX, NK.I1517.0F2)	6B.A6MN2.031
	UPPER CASE SILVER W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 104KS Black Japanese acer Font, Power icon, Media key, V0,NK.I1513.11Y,,)	6B.A6MN2.032
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black US International acer Font, Power icon, Media key, V0,NK.I1513.119, NK.I151S.0AT, NK.I1517.0EY)	6B.A9BN2.001

CATEGORY	Acer Description	AcerPN
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Greek acer Font, Power icon, Media key, V0,NK.I1513.113,NK.I151S.0AM,NK.I1517.0ES)	6B.A9BN2.002
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Arabic acer Font, Power icon, Media key, V0,NK.I1513.111,NK.I151S.0AK,NK.I1517.0EQ)	6B.A9BN2.003
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Traditional Chinese acer Font, Power icon, Media key, V0,NK.I1513.112, NK.I151S.0AL, NK.I1517.0ER)	6B.A9BN2.004
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Russian acer Font, Power icon, Media key, V0,NK.I1513.115,NK.I151S.0AP,NK.I1517.0EU)	6B.A9BN2.005
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black US International w/ Hebrew acer Font, Power icon, Media key, V0,NK.I1513.11A, NK.I151S.0AU, NK.I1517.0EZ)	6B.A9BN2.006
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Thailand acer Font, Power icon, Media key, V0,NK.I1513.118,NK.I151S.0AS,NK.I1517.0EX)	6B.A9BN2.007
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Korean acer Font, Power icon, Media key, V0,NK.I1513.114,NK.I151S.0AN,NK.I1517.0ET)	6B.A9BN2.008
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Ukrainian acer Font, Power icon, Media key, V0,NK.I1513.116,NK.I151S.0AQ,NK.I1517.0EV)	6B.A9BN2.009
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Persian acer Font, Power icon, Media key, V0,NK.I1513.117,NK.I151S.0AR,NK.I1517.0EW)	6B.A9BN2.010
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black US International w/ Canadian French acer Font, Power icon, Media key, V0,NK.I1513.11B, NK.I151S.0AV, NK.I1517.0F0)	6B.A9BN2.011

CATEGORY	Acer Description	AcerPN
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black US International w/ Bulgaria acer Font, Power icon, Media key, V0,NK.I1513.11C, NK.I151S.0AW, NK.I1517.0F1)	6B.A9BN2.012
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black UK acer Font, Power icon, Media key, V0,NK.I1513.11X,NK.I151S.0BF,NK.I1517.0FL)	6B.A9BN2.013
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black German acer Font, Power icon, Media key, V0,NK.I1513.11L,NK.I151S.0B4,NK.I1517.0F9)	6B.A9BN2.014
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Swiss/G acer Font, Power icon, Media key, V0,NK.I1513.11V,NK.I151S.0BD,NK.I1517.0FJ)	6B.A9BN2.015
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Belgium acer Font, Power icon, Media key, V0,NK.I1513.11E,NK.I151S.0AY,NK.I1517.0F3)	6B.A9BN2.016
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Danish acer Font, Power icon, Media key, V0,NK.I1513.11H,NK.I151S.0B1,NK.I1517.0F6)	6B.A9BN2.017
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Italian acer Font, Power icon, Media key, V0,NK.I1513.11N,NK.I151S.0B6,NK.I1517.0FB)	6B.A9BN2.018
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black French acer Font, Power icon, Media key, V0,NK.I1513.11K,NK.I151S.0B3,NK.I1517.0F8)	6B.A9BN2.019
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Hungarian acer Font, Power icon, Media key, V0,NK.I1513.11M, NK.I151S.0B5, NK.I1517.0FA)	6B.A9BN2.020
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Norwegian acer Font, Power icon, Media key, V0,NK.I1513.11Q, NK.I151S.0B8, NK.I1517.0FD)	6B.A9BN2.021

CATEGORY	Acer Description	AcerPN
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Portuguese acer Font, Power icon, Media key, V0,NK.I1513.11R, NK.I151S.0B9, NK.I1517.0FE)	6B.A9BN2.022
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Spanish acer Font, Power icon, Media key, V0,NK.I1513.11T,NK.I151S.0BB,NK.I1517.0FG)	6B.A9BN2.023
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Turkish acer Font, Power icon, Media key, V0,NK.I1513.11W,NK.I151S.0BE,NK.I1517.0FK)	6B.A9BN2.024
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Sweden acer Font, Power icon, Media key, V0,NK.I1513.11U,NK.I151S.0BC,NK.I1517.0FH)	6B.A9BN2.025
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black FR/Arabic acer Font, Power icon, Media key, V0,NK.I1513.11J,NK.I151S.0B2,NK.I1517.0F7)	6B.A9BN2.026
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Nordic acer Font, Power icon, Media key, V0,NK.I1513.11P,NK.I151S.0B7,NK.I1517.0FC)	6B.A9BN2.027
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black SLO/CRO acer Font, Power icon, Media key, V0,NK.I1513.11S,NK.I151S.0BA,NK.I1517.0FF)	6B.A9BN2.028
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black CZ/SK acer Font, Power icon, Media key, V0,NK.I1513.11G,NK.I151S.0B0,NK.I1517.0F5)	6B.A9BN2.029
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Brazilian Portuguese acer Font, Power icon, Media key, V0,NK.I1513.11F, NK.I151S.0AZ, NK.I1517.0F4)	6B.A9BN2.030
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black ALA-Spanish acer Font, Power icon, Media key, V0,NK.I1513.11D, NK.I151S.0AX, NK.I1517.0F2)	6B.A9BN2.031

CATEGORY	Acer Description	AcerPN
	UPPER CASE BLUE W/NBL(Keyboard SV05T_A72B SV5T Internal 15 Standard 104KS Black Japanese acer Font, Power icon, Media key, V0,NK.I1513.11Y)	6B.A9BN2.032
MAINBOARD		
	Mainboard A315-58 Intel Ci31115G4 4GB UMA	NB.ADD11.001
	Mainboard A315-58 Intel Ci31115G4 8GB UMA	NB.ADD11.002
	Mainboard A315-58 Intel Ci51135G7 4GB UMA	NB.ADD11.003
	Mainboard A315-58 Intel Ci51135G7 8GB UMA	NB.ADD11.004
	Mainboard A315-58 Intel Ci71165G7 4GB UMA	NB.ADD11.005
	Mainboard A315-58 Intel Ci71165G7 8GB UMA	NB.ADD11.006
	Mainboard A315-58G Intel Ci31115G4 4GB N17SG5 2GB	NB.ADU11.001
	Mainboard A315-58G Intel Ci31115G4 8GB N17SG5 2GB	NB.ADU11.002
	Mainboard A315-58G Intel Ci51135G7 4GB N17SG5 2GB	NB.ADU11.003
	Mainboard A315-58G Intel Ci51135G7 8GB N17SG5 2GB	NB.ADU11.004
	Mainboard A315-58G Intel Ci71165G7 4GB N17SG5 2GB	NB.ADU11.005
	Mainboard A315-58G Intel Ci71165G7 8GB N17SG5 2GB	NB.ADU11.006
	Mainboard A315-58 Intel Ci31115G4 4GB UMA with 255M codec	NB.AT011.001
	Mainboard A315-58 Intel Ci31115G4 8GB UMA with 255M codec	NB.AT011.002
POINT DEVICE		
	TOUCHPAD ASSY SILVER-ELANTECH	56.A6MN2.001
	TOUCHPAD ASSY BLUE-ELANTECH	56.A9BN2.001
	TOUCHPAD ASSY SILVER-SYNAPTICS	56.A6MN2.002
	TOUCHPAD ASSY BLUE-SYNAPTICS	56.A9BN2.002
	TOUCHPAD ASSY SILVER-ELANTECH W/FP	56.AG0N2.001
	TOUCHPAD ASSY BLACK-ELANTECH W/FP	TBD

CATEGORY	Acer Description	AcerPN
SPEAKER		
	SPEAKER L	23.A6MN2.002
	SPEAKER R	23.A6MN2.003
MISCELLANEOUS		
	RUBBER FOR MIC	47.A6MN2.001
	CONDUCTIVE TAPE FOR TP	47.A6MN2.002
	BATT_ACETATE_TAPE	47.Q7KN2.007
	LCD PANEL ADHESIVE	47.A6MN2.003
	LCD ALIGNMENT MYLAR 10x5x0.4mm	47.Q55N2.002

Screw List

Table 6-5. Screw List

CATEGORY	Description	Part No.
SCREWS		
	SCREW 2.0D 2.5L K 5D 0.5T NI NL	86.H14N2.001
	SCREW 2.5D 2.5L K 8D 0.6T ZK NL	86.H14N2.002
	SCREW 2.5D 5.0L K 4.6D NI NL	86.H14N2.003
	SCREW 3.0D 4.0L K 4.6D BNI	86.HZWN2.001
	SCREW M M 2.0D 4.0L K 4.6D BNI NL	86.Q99N2.001
	SCREW 2.5D 6L K 4.6D ZK NL	86.GD0N2.007
	SCREW 2D 3L K 4.5D ZK NL CR3 0.4T	86.GCHN2.009
	SCREW 2D 2.3L K 7D 0.5T ZK NL	86.A1DN2.001