

# Exploded Diagrams




Figure 6-1. System Exploded Diagram (A515-44/A515-44G/A515-44S)

**Table 6-1. System Exploded Diagram (A515-44/A515-44G/A515-44S)**

No.	Description	Acer Part No.
1	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Arabic, White BL NK.I1513.103	6B.HWBN7.001
2	TOUCHPAD ASSY BLACK W/BKT, MYLAR SYN NC.24611.05J	56.HW3N7.001
3	Mainboard A515-44 AMD R34300U UMA	NB.HVZ11.007
4	USB BOARD	55.HWDN7.001
5	FFC CABLE - USB BOARD	50.HWDN7.001
6	FFC CABLE - FINGER PRINT TOUCHPAD	50.HWDN7.002
7	THERMAL MODULE - DIS R19M-P18 RX640	24.HWDN7.001
	THERMAL MODULE - UMA	24.HVZN7.001
8	FAN DC 5V	23.HGLN7.001
9	ACETATE TAPE FOR BATTERY(21*21mm)	47.HKKN7.001
	ACETATE TAPE FOR KEYBOARD	47.HNBN7.001
10	SPEAKER (W-L/R)	23.HGLN7.002
11	HDD WD 2.5" 5400rpm 1000GB WD10SPZX-21Z10T0 , 7mmzh 1D , 1TB/P , MN1000S SATA III 128MB LF FW: 02.01A02	KH.01K08.035
12	HDD BRACKET	33.HGLN7.001
13	FFC CABLE FOR HDD(12P/17P,5V)	50.HGLN7.003
14	Memory MICRON SO-DIMM DDRIV 3200 4GB MTA4ATF51264HZ-3G2J1 LF+HF 512*16 Z21C	KN.4GB04.022
15	Liteon 3rd WiFi 2x2 AC+ BT M.2 QCA NFA344A MU-MIMO	NC.23611.030
16	Flash Disk HYNIX SSD NAND 128GB HFM128GDJTNG-8310A LF+HF	KN.1280G.006
17	Battery MURATA Typ.48Wh 4200mAh 3S1P 248x84.4x5.5(mm) AP18C 11.4V 60W Polymer	KT.00304.012
18	LOWER CASE BLACK	60.HW1N7.001




Figure 6-2. System Exploded Diagram (A515-45/A515-45G/A515-45S)

**Table 6-2. System Exploded Diagram (A515-45/A515-45G/A515-45S)**

No.	Description	Acer Part No.
1	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Arabic, White BL NK.I1513.103	6B.HWBN7.001
2	TOUCHPAD ASSY BLACK W/BKT, MYLAR SYN NC.24611.05J	56.HW3N7.001
3	Mainboard A515-45 AMD R55500U 8GB UMA	NB.A7Y11.005
4	USB BOARD	55.HWDN7.001
5	INSULATOR MYLAR FOR CABLE	47.HNBN7.002
6	HEAT SINK 15W UMA	24.A7YN7.001
	HEAT SINK 15W DIS	24.A7YN7.002
7	FAN DC 5V	23.HGLN7.001
8	FFC CABLE FOR TOUCH PAD(145.5MM,8P,3V)	50.HGLN7.001
9	FFC CABLE - USB BOARD	50.HWDN7.001
10	CONDUCTIVE TAPE	47.HWDN7.001
11	SPEAKER (W-L/R)	23.HGLN7.002
12	HDD BRACKET	33.HGLN7.001
13	FFC CABLE FOR HDD(12P/17P,5V)	50.HGLN7.003
14	Memory KINGSTON SO-DIMM DDRIV 2666 4GB ACR26D4S9S1KA-4 LF+HF 512*16 NA-A	KN.4GB07.043
15	Liteon 3rd WiFi 2x2 AC+ BT M.2 QCA NFA344A MU-MIMO	NC.23611.030
16	Flash Disk SAMSUNG SSD NAND 128GB M.2 2280 PM991 MZVLQ128HBHQ-00000 FW# FXV7101Q LF+HF	KN.1280B.011
17	Battery LGC AP18C Polymer 3S1P LGC 3 cell 4343mAh Main COMMON	KT.0030G.020
18	HDD WD 2.5" 5400rpm 1000GB WD10SPZX-21Z10T0 , 7mmzh 1D , 1TB/P , MN1000S SATA III 128MB LF F/W: 02.01A02	KH.01K08.035
19	LOWER CASE BLACK	60.A7YN7.001




Figure 6-3. System Exploded Diagram (A515-46)

**Table 6-3. System Exploded Diagram (A515-46)**

No.	Description	Acer Part No.
1	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Arabic, White BL NK.I1513.103	6B.HWBN7.001
2	TOUCHPAD ASSY BLACK W/BKT, MYLAR SYN NC.24611.05J	56.HW3N7.001
3	Mainboard	
4	USB BOARD	55.HWDN7.001
5	INSULATOR MYLAR FOR CABLE	47.HNBN7.002
6	Heatsink	
7	FAN DC 5V	23.HGLN7.001
8	FFC CABLE FOR TOUCH PAD(145.5MM,8P,3V)	50.HGLN7.001
9	FFC CABLE - USB BOARD	50.HWDN7.001
10	CONDUCTIVE TAPE	47.HWDN7.001
11	SPEAKER (W-L/R)	23.HGLN7.002
12	HDD BRACKET	33.HGLN7.001
13	FFC CABLE FOR HDD(12P/17P,5V)	50.HGLN7.003
14	Memory MICRON SO-DIMM DDRIV 3200 4GB MTA4ATF51264HZ-3G2J1 LF+HF 512*16 Z21C	KN.4GB04.022
15	Wireless LAN Intel 802.11ax Bluetooth FM AX200.NGWG.NV WiFi 6 CcP2 M.2 2X2 AX + BT 5.0 2230 No vPro (AX200.NGWG.NV-MM#985927 )	KE.11X0N.003
16	Flash Disk SANDISK SSD NAND 256GB BiCS4 SN530 SDBPNPZ-256G-1114 LF+HF	KN.2560D.017
17	Battery LGC AP18C Polymer 3S1P LGC 3 cell 4343mAh Main COMMON	KT.0030G.020
18	HDD WD 2.5" 5400rpm 1000GB WD10SPZX-21Z10T0 , 7mmzh 1D , 1TB/P , MN1000S SATA III 128MB LF F/W: 02.01A02	KH.01K08.035
19	LOWER CASE SILVER	60.HVZN7.001




Figure 6-4. LCD Assembly Exploded Diagram

Table 6-4. LCD Assembly Exploded Diagram

No.	Description	Acer Part No.
1	LCD BEZEL W/HINGE CAP BLACK	60.HGLN7.003
2	LED LCD Panel CMI 15.6"W WXGA None Glare N156BGA-EA3 LF 220nit 10ms 500:1 (eDP, 3.2mm Max,narrow border)	KL.1560D.034
3	Camera Tech-Front HD Camera HD Camera TF_OV9734_SP2087L2_AOET_KMM4030 Unified2 (add Mic*2)	KS.0HD0Q.004
4	LCD CABLE	50.HWDN7.003
5	HINGE L	33.HGLN7.002
	HINGE R	33.HGLN7.003
6	ANTENNA (MAIN+AUX,NGFF)	50.HGLN7.004

**Table 6-4. LCD Assembly Exploded Diagram (Continued)**

No.	Description	Acer Part No.
7	LCD COVER ASSY BLACK	60.HGLN7.002



# FRU List

Table 6-5. FRU List (A515-44/A515-44G/A515-44S)

Category	Part Description	Acer Part No.
<b>ADAPTER</b>		
	Adapter DELTA 45W 19V 1.1x3.0x7.7 ADP-45FE FD LF Black 45W_3phy	KP.04501.017
	Adapter LITE-ON 45W 19V 1.1x3.0x7.7 PA-1450-26A3 LF Black	KP.04503.011
	Adapter Chicony Power 45W 19V 1.1x3.0x7.7 Black A045R072P LF Black Meet CoC Tier2 & IEC 62368, No acer logo	KP.0450H.013
	Adapter DELTA 65W 19V 1.1x3.0x7.7 ADP-65DE BA LF Black Meet DOE6, CoC Tier2, IEC 62368	KP.06501.012
	Adapter LITE-ON 65W 19V 1.1x3.0x7.7 PA-1650-50A3 LF BLACK Meet DOE6, CoC Tier2, IEC 62368	KP.06503.018
	Adapter Chicony Power 65W 19V 1.1x3.0x7.7 Yellow A065R178P LF Black Meet IEC62368 & CoC Tier2, no acer logo	KP.0650H.013
<b>BATTERY</b>		
	Battery MURATA Typ.48Wh 4200mAh 3S1P 248x84.4x5.5(mm) AP18C 11.4V 60W Polymer	KT.00304.012
	Battery LGC AP18C Polymer 3S1P LGC 3 cell 4343mAh Main COMMON	KT.0030G.020
	Battery PANASONIC Typ.55Wh 3550mAh 4S1P 248x84.4x5.5(mm) AP19B 15.4V 70W Polymer	KT.00405.010
<b>BOARD</b>		
	Liteon 3rd WiFi 2x2 AC+ BT M.2 QCA NFA344A MU-MIMO	NC.23611.030
	Wireless LAN Intel 802.11ax Bluetooth FM AX200.NGWG.NV WiFi 6 CcP2 M.2 2X2 AX + BT 5.0 2230 No vPro (AX200.NGWG.NV-MM#985927 )	KE.11X0N.003
	USB BOARD	55.HWDN7.001

**Table 6-5. FRU List (A515-44/A515-44G/A515-44S) (Continued)**

Category	Part Description	Acer Part No.
	TOUCHPAD ASSY BLACK W/BKT, MYLAR SYN NC.24611.05J	56.HW3N7.001
	TOUCHPAD ASSY BLACK W/BKT, MYLAR ELAN NC.24611.05Z	56.HW3N7.002
	TOUCHPAD ASSY W/ FINGER PRINT BLACK ELAN NC.24611.061	56.HW7N7.001
	TOUCHPAD ASSY SILVER W/BKT, MYLAR SYN NC.24611.05J	56.HW4N7.001
	TOUCHPAD ASSY SILVER W/BKT, MYLAR ELAN NC.24611.05Z	56.HW4N7.002
	TOUCHPAD ASSY W/ FINGER PRINT SILVER ELAN NC.24611.061	56.HW8N7.001
<b>CABLE</b>		
	FFC CABLE - USB BOARD	50.HWDN7.001
	FFC CABLE - FINGER PRINT TOUCHPAD	50.HWDN7.002
	FFC CABLE FOR TOUCH PAD(145.5MM,8P,3V)	50.HGLN7.001
	FFC CABLE FOR HDD(12P/17P,5V)	50.HGLN7.003
	ANTENNA (MAIN+AUX,NGFF)	50.HGLN7.004
	LCD CABLE	50.HWDN7.003

**Table 6-5. FRU List (A515-44/A515-44G/A515-44S) (Continued)**

Category	Part Description	Acer Part No.
<b>CAMERA</b>		
	Camera Tech-Front HD Camera HD Camera TF_OV9734_SP2087L2_AOET_KMM4030 Unified2 (add Mic*2)	KS.0HD0Q.004
	Camera CHICONY HD Camera HD Camera CH_OV9734_RTS5846N_AOET_SPK0493 Unified2 (add Mic*2)	KS.0HD06.012
<b>CASE/COVER/BRACKET ASSEMBLY</b>		
	LOWER CASE BLACK	60.HW1N7.001
	LOWER CASE SILVER	60.HVZN7.001
	HDD BRACKET	33.HGLN7.001
	LCD COVER ASSY BLACK	60.HGLN7.002
	LCD COVER ASSY SILVER	60.HFQN7.002
	LCD BEZEL W/HINGE CAP BLACK	60.HGLN7.003
	LCD BEZEL (W/HINGE CAP)SILVER	60.HFQN7.003
	HINGE L	33.HGLN7.002
	HINGE R	33.HGLN7.003
<b>FAN SINK/SPEAKER/EARPHONE/RTC</b>		
	FAN DC 5V	23.HGLN7.001


**Table 6-5. FRU List (A515-44/A515-44G/A515-44S) (Continued)**

Category	Part Description	Acer Part No.
	THERMAL MODULE - DIS R19M-P18 RX640	24.HWDN7.001
	THERMAL MODULE - UMA	24.HVZN7.001
	SPEAKER (W-L/R)	23.HGLN7.002
<b>HDD/HARD DISK DRIVE</b>		
	HDD WD 2.5" 5400rpm 1000GB WD10SPZX-21Z10T0, 7mmzh 1D, 1TB/P, MN1000S SATA III 128MB LF F/W: 02.01A02	KH.01K08.035
	HDD TOSHIBA 2.5" 5400rpm 1000GB MQ04ABF100, 1TB/P, acer code SATA III 128MB LF+HF F/W:JU002J	KH.01K04.017
	HDD SEAGATE 2.5" 5400rpm 1000GB ST1000LM035, 1RK172-192, Rosewood 1TB ,7mmzh HDD - SATA III 128MB LF F/W:ADM1	KH.01K01.075
	HDD WD 2.5" 5400rpm 2000GB WD20SPZX-21UA7T0, 7mmzh 2D, 1TB/P, MN1000M SATA III 128MB LF F/W:01.01A01	KH.02K08.020
	Flash Disk HYNIX SSD NAND 128GB HFM128GDJTNG-8310A LF+HF	KN.1280G.006
	Flash Disk SANDISK SSD NAND 128GB SDAPNUW-128G-1014 LF+HF	KN.1280D.010
	Flash Disk SANDISK SSD NAND 256GB SDAPNUW-256G-1014 LF+HF	KN.2560D.010
	Flash Disk HYNIX SSD NAND 256GB M.2 2280 BC511 HFM256GDJTNI-82A0A LF+HF	KN.2560G.029
	Flash Disk HYNIX SSD NAND 512GB M.2 2280 BC511 HFM512GDJTNI-82A0A LF+HF	KN.5120G.033
	Flash Disk SANDISK SSD NAND 512GB SDAPNUW-512G-1014 LF+HF	KN.5120D.004
	Flash Disk INTEL SSD NAND 1024GB Intel 660p SSDPEKNW010T8 LF+HF	KN.01K0N.004


**Table 6-5. FRU List (A515-44/A515-44G/A515-44S) (Continued)**

Category	Part Description	Acer Part No.
<b>KEYBOARD ASSEMBLY</b>		
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Arabic, White BL NK.I1513.103	6B.HWBN7.001
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black FR/Arabic, White BL NK.I1513.10L	6B.HWBN7.002
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Belgium, White BL NK.I1513.10G	6B.HWBN7.003
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Brazilian Portuguese, White BL NK.I1513.10H	6B.HWBN7.004
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black US International w/ Bulgaria, White BL NK.I1513.10E	6B.HWBN7.005
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black US International w/ Canadian French, White BL NK.I1513.10D	6B.HWBN7.006
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black SLO/CRO, White BL NK.I1513.10U	6B.HWBN7.007
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black CZ/SK, White BL NK.I1513.10J	6B.HWBN7.008
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Danish, White BL NK.I1513.10K	6B.HWBN7.009
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black French, White BL NK.I1513.10M	6B.HWBN7.010


**Table 6-5. FRU List (A515-44/A515-44G/A515-44S) (Continued)**

Category	Part Description	Acer Part No.
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black German, White BL NK.I1513.10N	6B.HWBN7.011
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Greek, White BL NK.I1513.105	6B.HWBN7.012
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black US International w/ Hebrew, White BL NK.I1513.10C	6B.HWBN7.013
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Hungarian, White BL NK.I1513.10P	6B.HWBN7.014
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Persian, White BL NK.I1513.109	6B.HWBN7.015
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Italian, White BL NK.I1513.10Q	6B.HWBN7.016
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 104KS Black Japanese, White BL NK.I1513.110	6B.HWBN7.017
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Korean, White BL NK.I1513.106	6B.HWBN7.018
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black ALA-Spanish, White BL NK.I1513.10F	6B.HWBN7.019
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Norwegian, White BL NK.I1513.10S	6B.HWBN7.020
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Portuguese, White BL NK.I1513.10T	6B.HWBN7.021

**Table 6-5. FRU List (A515-44/A515-44G/A515-44S) (Continued)**


Category	Part Description	Acer Part No.
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Russian, White BL NK.I1513.107	6B.HWBN7.022
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Nordic, White BL NK.I1513.10R	6B.HWBN7.023
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Spanish, White BL NK.I1513.10V	6B.HWBN7.024
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Sweden, White BL NK.I1513.10W	6B.HWBN7.025
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Swiss/G, White BL NK.I1513.10X	6B.HWBN7.026
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Traditional Chinese, White BL NK.I1513.104	6B.HWBN7.027
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Thailand, White BL NK.I1513.10A	6B.HWBN7.028
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Turkish, White BL NK.I1513.10Y	6B.HWBN7.029
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black US International, White BL NK.I1513.10B	6B.HWBN7.030
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black UK, White BL NK.I1513.10Z	6B.HWBN7.031
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Ukrainian, White BL NK.I1513.108	6B.HWBN7.032

**Table 6-5. FRU List (A515-44/A515-44G/A515-44S) (Continued)**



Category	Part Description	Acer Part No.
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Nordic NK.I1517.0FC/NK.I1515.0B7/NK.I1513.11P	6B.HW7N7.023
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Spanish NK.I1517.0FG/NK.I1515.0BB/NK.I1513.11T	6B.HW7N7.024
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Sweden NK.I1517.0FH/NK.I1515.0BC/NK.I1513.11U	6B.HW7N7.025
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Swiss/G NK.I1517.0FJ/NK.I1515.0BD/NK.I1513.11V	6B.HW7N7.026
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Traditional Chinese NK.I1517.0ER/NK.I1515.0AL/NK.I1513.112	6B.HW7N7.027
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Thailand NK.I1517.0EX/NK.I1515.0AS/NK.I1513.118	6B.HW7N7.028
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Turkish NK.I1517.0FK/NK.I1515.0BE/NK.I1513.11W	6B.HW7N7.029
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black US International NK.I1517.0EY/NK.I1515.0AT/NK.I1513.119	6B.HW7N7.030
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black UK NK.I1517.0FL/NK.I1515.0BF/NK.I1513.11X	6B.HW7N7.031
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Ukrainian NK.I1517.0EV/NK.I1515.0AQ/NK.I1513.116	6B.HW7N7.032
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Arabic, White BL NK.I1513.103	6B.HWCN7.001






**Table 6-5. FRU List (A515-44/A515-44G/A515-44S) (Continued)**

Category	Part Description	Acer Part No.
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Spanish, White BL NK.I1513.10V	6B.HWCN7.024
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Sweden, White BL NK.I1513.10W	6B.HWCN7.025
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Swiss/G, White BL NK.I1513.10X	6B.HWCN7.026
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Traditional Chinese, White BL NK.I1513.104	6B.HWCN7.027
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Thailand, White BL NK.I1513.10A	6B.HWCN7.028
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Turkish, White BL NK.I1513.10Y	6B.HWCN7.029
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black US International, White BL NK.I1513.10B	6B.HWCN7.030
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black UK, White BL NK.I1513.10Z	6B.HWCN7.031
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Ukrainian, White BL NK.I1513.108	6B.HWCN7.032
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Arabic NK.I1517.0EQ/NK.I151S.0AK/NK.I1513.111	6B.HW8N7.001
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black FR/Arabic NK.I1517.0F7/NK.I151S.0B2/NK.I1513.11J	6B.HW8N7.002







**Table 6-5. FRU List (A515-44/A515-44G/A515-44S) (Continued)**

Category	Part Description	Acer Part No.
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Sweden NK.I1517.0FH/NK.I151S.0BC/NK.I1513.11U	6B.HW8N7.025
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Swiss/G NK.I1517.0FJ/NK.I151S.0BD/NK.I1513.11V	6B.HW8N7.026
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Traditional Chinese NK.I1517.0ER/NK.I151S.0AL/NK.I1513.112	6B.HW8N7.027
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Thailand NK.I1517.0EX/NK.I151S.0AS/NK.I1513.118	6B.HW8N7.028
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Turkish NK.I1517.0FK/NK.I151S.0BE/NK.I1513.11W	6B.HW8N7.029
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black US International NK.I1517.0EY/NK.I151S.0AT/NK.I1513.119	6B.HW8N7.030
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black UK NK.I1517.0FL/NK.I151S.0BF/NK.I1513.11X	6B.HW8N7.031
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Ukrainian NK.I1517.0EV/NK.I151S.0AQ/NK.I1513.116	6B.HW8N7.032
<b>LCD</b>		
	LED LCD Panel CMI 15.6"W WXGA None Glare N156BGA-EA3 LF 220nit 10ms 500:1 (eDP, 3.2mm Max,narrow border)	KL.1560D.034
	LED LCD Panel AUO 15.6"W WXGA None Glare B156XTN08.1 LF 220nit 8ms 400:1 (eDP, 3.2mm Max, narrow border)	KL.15605.048
	LED LCD Panel AUO 15.6"W FHD None Glare B156HTN06.1 LF 220nit 8ms 400:1 (eDP, narrow border, 3.2mm max, value)	KL.15605.050

**Table 6-5. FRU List (A515-44/A515-44G/A515-44S) (Continued)**

Category	Part Description	Acer Part No.
	LED LCD Panel CMI 15.6"W FHD None Glare N156HGA-EA3 LF 220nit 10ms 500:1 (eDP, narrow border, 3.2mm max, value)	KL.1560D.035
	LED LCD Panel BOE 15.6"W FHD None Glare NT156FHM-N61 LF 220nit 10ms 500:1 (eDP, narrow border, 3.2mm max, value)	KL.1560E.015
	LED LCD Panel Panda 15.6"W FHD None Glare LM156LFCL03 LF 220nit 25ms 1000:1 (eDP, value IPS, narrow border)	KL.15603.004
	LED LCD Panel LPL 15.6"W FHD None Glare LP156WFC-SPD5 LF 250nit 25ms 700:1 (eDP, Value IPS,narrow, 3.2mm max)	KL.15608.043
	LED LCD Panel AUO 15.6"W FHD None Glare B156HAN02.1 H/W:4B LF 250nit 25ms 700:1 (eDP, value IPS, narrow border)	KL.15605.062
<b>MAINBOARD</b>		
 	Mainboard A515-44 AMD R34300U UMA	NB.HVZ11.007
	Mainboard A515-44 AMD R54500U UMA	NB.HVZ11.008
	Mainboard A515-44 AMD R74700U UMA	NB.HVZ11.009
	Mainboard A515-44 AMD R74700U 4GB UMA	NB.HVZ11.005
	Mainboard A515-44 AMD R34300U 4GB UMA	NB.HVZ11.001
	Mainboard A515-44 AMD R34300U 8GB UMA	NB.HVZ11.002
	Mainboard A515-44 AMD R54500U 4GB UMA	NB.HVZ11.004
	Mainboard A515-44 AMD R54500U 8GB UMA	NB.HVZ11.003
	Mainboard A515-44 AMD R74700U 8GB UMA	NB.HVZ11.006
	Mainboard A515-44G AMD R34300U R19M-P18-50 2GB	NB.HW911.001
	Mainboard A515-44G AMD R54500U R19M-P18-50 2GB	NB.HWA11.001
	Mainboard A515-44G AMD R74700U R19M-P18-50 2GB	NB.HW911.006
	Mainboard A515-44G AMD R34300U 4GB R19M-P18-50 2GB	NB.HW911.002
	Mainboard A515-44G AMD R54500U 4GB R19M-P18-50 2GB	NB.HW011.001
	Mainboard A515-44G AMD R54500U 8GB R19M-P18-50 2GB	NB.HW911.004
Mainboard A515-44G AMD R74700U 4GB R19M-P18-50 2GB	NB.HW911.005	

**Table 6-5. FRU List (A515-44/A515-44G/A515-44S) (Continued)**

Category	Part Description	Acer Part No.
	Mainboard A515-44G AMD R74700U 8GB R19M-P18-50 2GB	NB.HWE11.001
<b>MEMORY</b>		
	Memory MICRON SO-DIMM DDRIV 3200 4GB MTA4ATF51264HZ-3G2J1 LF+HF 512*16 Z21C	KN.4GB04.022
	Memory HYNIX SO-DIMM DDRIV 2666 4GB HMA851S6CJR6N-VK LF+HF 512*16 1Xnm, AL	KN.4GB0G.049
	Memory HYNIX SO-DIMM DDRIV 2666 8GB HMA81GS6CJR8N-VK LF+HF 1024*8 1Xnm, AL	KN.8GB0G.058
	Memory KINGSTON SO-DIMM DDRIV 2666 8GB ACR26D4S9S8HJ-8 LF+HF HY-J die	KN.8GB07.051
	Memory KINGSTON SO-DIMM DDRIV 2666 16GB ACR26D4S9D8ME-16 LF+HF 1024*8	KN.16G07.028
	Memory HYNIX SO-DIMM DDRIV 2666 16GB HMA82GS6CJR8N-VK LF+HF 1024*8 1Xnm, AL	KN.16G0G.031
<b>MISCELLANEOUS</b>		
	LCD ADHESIVE TAPE	47.HGLN7.001
	RUBBER FOR MIC	47.HGLN7.002
	CONDUCTIVE TAPE	47.HWDN7.001
	INSULATOR MYLAR FOR CABLE	47.HNBN7.002








**Table 6-5. FRU List (A515-44/A515-44G/A515-44S) (Continued)**

Category	Part Description	Acer Part No.
	ACETATE TAPE FOR BATTERY(21*21mm)	47.HKKN7.001
	ACETATE TAPE FOR KEYBOARD	47.HNBN7.001
	INS MYLAR FOR LCD PANEL	47.HKCN7.001
<b>POWER CORD</b>		
	POWER CORD 1M 125V JAP BLACK	27.NE307.001
	POWER CORD 1M 125V ARG BLACK	27.NE307.004
	POWER CORD 1M 125V AUS BLACK	27.NE307.005
	POWER CORD 1M 125V BRAZIL BLACK	27.NE307.006
	POWER CORD 1M 125V CHINA BLACK	27.NE307.007
	POWER CORD 1M 125V DENMARK BLACK	27.NE307.008
	POWER CORD 1M 125V INDIA BLACK	27.NE307.009
	POWER CORD 1M 125V ISRAEL BLACK	27.NE307.010
	POWER CORD 1M 125V ITL BLACK	27.NE307.011
	POWER CORD 1M 125V S.AFRICA BLACK	27.NE307.012
	POWER CORD 1M 125V SWISS BLACK	27.NE307.013
	POWER CORD 1M 125V EUR+KOR BLACK	27.NE307.015
	POWER CORD 1M 125V US BLACK	27.NE307.003
	POWER CORD 1M 125V UK BLACK	27.NE307.014
POWER CORD 1M 125V TAIWAN BLACK	27.NE307.002	

**Table 6-6. FRU List (A515-45/A515-45G/A515-45S)**

CATEGORY	PART DESCRIPTION	ACER PARTNO
<b>Adapter</b>		
	Adapter DELTA 45W 19V 1.1x3.0x7.7 ADP-45FE FD LF Black 45W_3phy	KP.04501.017
	Adapter DELTA 65W 19V 1.1x3.0x7.7 ADP-65DE BA LF Black Meet DOE6, CoC Tier2, IEC 62368	KP.06501.012
	Adapter Chicony Power 65W 19V 1.1x3.0x7.7 Yellow A065R178P LF Black Meet IEC62368 & CoC Tier2, no acer logo	KP.0650H.013
<b>Battery</b>		
	Battery LGC AP18C Polymer 3S1P LGC 3 cell 4343mAh Main COMMON	KT.0030G.020
	Battery PANASONIC Typ.55Wh 3550mAh 4S1P 248x84.4x5.5(mm) AP19B 15.4V 70W Polymer	KT.00405.010
<b>Board</b>		
	Liteon 3rd WiFi 2x2 AC+ BT M.2 QCA NFA344A MU-MIMO	NC.23611.030
	Wireless LAN Intel 802.11ax Bluetooth FM AX200.NG.WG.NV WiFi 6 CcP2 M.2 2X2 AX + BT 5.0 2230 No vPro (AX200.NG.WG.NV-MM#985927 )	KE.11X0N.003
	USB BOARD	55.HWDN7.001
	TOUCHPAD ASSY BLACK W/BKT, MYLAR SYN NC.24611.05J	56.HW3N7.001
	TOUCHPAD ASSY BLACK W/BKT, MYLAR ELAN NC.24611.05Z	56.HW3N7.002
	TOUCHPAD ASSY W/ FINGER PRINT BLACK ELAN NC.24611.061	56.HW7N7.001
	TOUCHPAD ASSY SILVER W/BKT, MYLAR SYN NC.24611.05J	56.HW4N7.001
	TOUCHPAD ASSY SILVER W/BKT, MYLAR ELAN NC.24611.05Z	56.HW4N7.002
	TOUCHPAD ASSY W/ FINGER PRINT SILVER ELAN NC.24611.061	56.HW8N7.001

**Table 6-6. FRU List (A515-45/A515-45G/A515-45S) (Continued)**






CATEGORY	PART DESCRIPTION	ACER PARTNO
<b>Cable</b>		
	FFC CABLE - USB BOARD	50.HWDN7.001
	FFC CABLE - FINGER PRINT TOUCHPAD	50.HWDN7.002
	FFC CABLE FOR TOUCH PAD(145.5MM,8P,3V)	50.HGLN7.001
	FFC CABLE FOR HDD(12P/17P,5V)	50.HGLN7.003
	ANTENNA (MAIN+AUX,NGFF)	50.HGLN7.004
	LCD CABLE	50.HWDN7.003
<b>Camera</b>		
	Camera Tech-Front HD Camera HD Camera TF_OV9734_SP2087L2_AOET_KMM4030 Unified2 (add Mic*2)	KS.0HD0Q.004
	Camera CHICONY HD Camera HD Camera CH_OV9734_RTS5846N_AOET_SPK0493 Unified2 (add Mic*2)	KS.0HD06.012

**Table 6-6. FRU List (A515-45/A515-45G/A515-45S) (Continued)**


CATEGORY	PART DESCRIPTION	ACER PARTNO
<b>Case/Cover/Bracket Assembly</b>		
	LOWER CASE BLACK	60.A7YN7.001
	LOWER CASE SILVER	60.A7YN7.002
	HDD BRACKET	33.HGLN7.001
	LCD COVER ASSY BLACK	60.HGLN7.002
	LCD COVER ASSY SILVER	60.HFQN7.002
	LCD BEZEL W/HINGE CAP BLACK	60.HGLN7.003
	LCD BEZEL (W/HINGE CAP)SILVER	60.HFQN7.003
	HINGE L	33.HGLN7.002
	HINGE R	33.HGLN7.003
<b>Fan Sink/Speaker/Earphone/RTC</b>		
	FAN DC 5V	23.HGLN7.001
	HEAT SINK 15W UMA	24.A7YN7.001




**Table 6-6. FRU List (A515-45/A515-45G/A515-45S) (Continued)**

CATEGORY	PART DESCRIPTION	ACER PARTNO
	HEAT SINK 15W DIS	24.A7YN7.002
	SPEAKER (W-L/R)	23.HGLN7.002
<b>HDD/Hard Disk Drive</b>		
	HDD WD 2.5" 5400rpm 1000GB WD10SPZX-21Z10T0 , 7mmzh 1D , 1TB/P , MN1000S SATA III 128MB LF F/W: 02.01A02	KH.01K08.035
	HDD TOSHIBA 2.5" 5400rpm 1000GB MQ04ABF100 , 1TB/P, acer code SATA III 128MB LF+HF F/W:JU002J	KH.01K04.017
	HDD SEAGATE 2.5" 5400rpm 1000GB ST1000LM035 ,1RK172-192 ,Rosewood 1TB ,7mmzh HDD - SATA III 128MB LF F/W:ADM1	KH.01K01.075
	HDD WD 2.5" 5400rpm 2000GB WD20SPZX-21UA7T0 , 7mmzh 2D , 1TB/P , MN1000M SATA III 128MB LF F/W:01.01A01	KH.02K08.020
	Flash Disk SAMSUNG SSD NAND 128GB M.2 2280 PM991 MZVLQ128HBHQ-00000 FW# FXV7101Q LF+HF	KN.1280B.011
	Flash Disk SANDISK SSD NAND 256GB BiCS4 SN530 SDBPNPZ-256G-1114 LF+HF	KN.2560D.017
	Flash Disk KINGSTON SSD NAND 512GB OM8PCP3512F-AA Kingston QLC LF+HF	KN.51207.011
	Flash Disk MICRON SSD NAND 1024GB M.2 2280 2210 MTFDHBA1T0QFD-1AX15ABYY LF+HF	KN.01K04.003
<b>Keyboard Assembly</b>		
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Arabic, White BL NK.I1513.103	6B.HWBN7.001


**Table 6-6. FRU List (A515-45/A515-45G/A515-45S) (Continued)**

CATEGORY	PART DESCRIPTION	ACER PARTNO
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Spanish, White BL NK.I1513.10V	6B.HWBN7.024
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Sweden, White BL NK.I1513.10W	6B.HWBN7.025
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Swiss/G, White BL NK.I1513.10X	6B.HWBN7.026
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Traditional Chinese, White BL NK.I1513.104	6B.HWBN7.027
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Thailand, White BL NK.I1513.10A	6B.HWBN7.028
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Turkish, White BL NK.I1513.10Y	6B.HWBN7.029
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black US International, White BL NK.I1513.10B	6B.HWBN7.030
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black UK, White BL NK.I1513.10Z	6B.HWBN7.031
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Ukrainian, White BL NK.I1513.108	6B.HWBN7.032
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Arabic NK.I1517.0EQ/NK.I151S.0AK/NK.I1513.111	6B.HW7N7.001
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black FR/Arabic NK.I1517.0F7/NK.I151S.0B2/NK.I1513.11J	6B.HW7N7.002



**Table 6-6. FRU List (A515-45/A515-45G/A515-45S) (Continued)**

CATEGORY	PART DESCRIPTION	ACER PARTNO
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Sweden NK.I1517.0FH/NK.I1515.0BC/NK.I1513.11U	6B.HW7N7.025
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Swiss/G NK.I1517.0FJ/NK.I1515.0BD/NK.I1513.11V	6B.HW7N7.026
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Traditional Chinese NK.I1517.0ER/NK.I1515.0AL/NK.I1513.112	6B.HW7N7.027
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Thailand NK.I1517.0EX/NK.I1515.0AS/NK.I1513.118	6B.HW7N7.028
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Turkish NK.I1517.0FK/NK.I1515.0BE/NK.I1513.11W	6B.HW7N7.029
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black US International NK.I1517.0EY/NK.I1515.0AT/NK.I1513.119	6B.HW7N7.030
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black UK NK.I1517.0FL/NK.I1515.0BF/NK.I1513.11X	6B.HW7N7.031
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Ukrainian NK.I1517.0EV/NK.I1515.0AQ/NK.I1513.116	6B.HW7N7.032
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Arabic, White BL NK.I1513.103	6B.HWCN7.001
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black FR/Arabic, White BL NK.I1513.10L	6B.HWCN7.002
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Belgium, White BL NK.I1513.10G	6B.HWCN7.003








**Table 6-6. FRU List (A515-45/A515-45G/A515-45S) (Continued)**

CATEGORY	PART DESCRIPTION	ACER PARTNO
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Swiss/G, White BL NK.I1513.10X	6B.HWCN7.026
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Traditional Chinese, White BL NK.I1513.104	6B.HWCN7.027
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Thailand, White BL NK.I1513.10A	6B.HWCN7.028
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Turkish, White BL NK.I1513.10Y	6B.HWCN7.029
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black US International, White BL NK.I1513.10B	6B.HWCN7.030
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black UK, White BL NK.I1513.10Z	6B.HWCN7.031
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Ukrainian, White BL NK.I1513.108	6B.HWCN7.032
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Arabic NK.I1517.0EQ/NK.I1515.0AK/NK.I1513.111	6B.HW8N7.001
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black FR/Arabic NK.I1517.0F7/NK.I1515.0B2/NK.I1513.11J	6B.HW8N7.002
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Belgium NK.I1517.0F3/NK.I1515.0AY/NK.I1513.11E	6B.HW8N7.003
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Brazilian Portuguese NK.I1517.0F4/NK.I1515.0AZ/NK.I1513.11F	6B.HW8N7.004



**Table 6-6. FRU List (A515-45/A515-45G/A515-45S) (Continued)**

CATEGORY	PART DESCRIPTION	ACER PARTNO
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Traditional Chinese NK.I1517.0ER/NK.I1515.0AL/NK.I1513.112	6B.HW8N7.027
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Thailand NK.I1517.0EX/NK.I1515.0AS/NK.I1513.118	6B.HW8N7.028
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Turkish NK.I1517.0FK/NK.I1515.0BE/NK.I1513.11W	6B.HW8N7.029
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black US International NK.I1517.0EY/NK.I1515.0AT/NK.I1513.119	6B.HW8N7.030
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black UK NK.I1517.0FL/NK.I1515.0BF/NK.I1513.11X	6B.HW8N7.031
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Ukrainian NK.I1517.0EV/NK.I1515.0AQ/NK.I1513.116	6B.HW8N7.032
<b>LCD</b>		
	LED LCD Panel CMI 15.6"W WXGA None Glare N156BGA-EA3 LF 220nit 10ms 500:1 (eDP, 3.2mm Max,narrow border)	KL.1560D.034
	LED LCD Panel AUO 15.6"W WXGA None Glare B156XTN08.1 LF 220nit 8ms 400:1 (eDP, 3.2mm Max, narrow border)	KL.15605.048
	LED LCD Panel AUO 15.6"W FHD None Glare B156HTN06.1 LF 220nit 8ms 400:1 (eDP, narrow border, 3.2mm max, value)	KL.15605.050
	LED LCD Panel CMI 15.6"W FHD None Glare N156HGA-EA3 LF 220nit 10ms 500:1 (eDP, narrow border, 3.2mm max, value)	KL.1560D.035
	LED LCD Panel BOE 15.6"W FHD None Glare NT156FHM-N61 LF 220nit 10ms 500:1 (eDP, narrow border, 3.2mm max, value)	KL.1560E.015
	LED LCD Panel BOE 15.6"W WXGA None Glare NT156WHM-N44 V8.0 LF 220nit 12ms 400:1 (eDP,3.2mm Max, narrow border)	KL.1560E.014

**Table 6-6. FRU List (A515-45/A515-45G/A515-45S) (Continued)**



CATEGORY	PART DESCRIPTION	ACER PARTNO
	LED LCD Panel LPL 15.6"W FHD None Glare LP156WFC-SPD5 LF 250nit 25ms 700:1 (eDP, Value IPS,narrow, 3.2mm max)	KL.15608.043
	LED LCD Panel AUO 15.6"W FHD None Glare B156HAN02.1 H/W:4B LF 250nit 25ms 700:1 (eDP, value IPS, narrow border)	KL.15605.062
<b>Mainboard</b>		
	Mainboard A515-45 AMD R55500U 8GB UMA	NB.A7Y11.005
	Mainboard A515-45G AMD R55500U 4GB R19M-P18-50 2GB	NB.A8711.001
	Mainboard A515-45G AMD R55500U 8GB R19M-P18-50 2GB	NB.A8A11.002
<b>Memory</b>		
	Memory KINGSTON SO-DIMM DDRIV 2666 4GB ACR26D4S9S1KA-4 LF+HF 512*16 NA-A	KN.4GB07.043
	Memory HYNIX SO-DIMM DDRIV 3200 16GB HMAA2GS6AJR8N-XN LF+HF AL prime	KN.16G0G.035
	Memory MICRON SO-DIMM DDRIV 3200 8GB MTA4ATF1G64HZ-3G2E1 LF+HF 1024*16 Z32D	KN.8GB04.048
<b>Miscellaneous</b>		
	LCD ADHESIVE TAPE	47.HGLN7.001
	RUBBER FOR MIC	47.HGLN7.002
	CONDUCTIVE TAPE	47.HWDN7.001
	INSULATOR MYLAR FOR CABLE	47.HNBN7.002

**Table 6-6. FRU List (A515-45/A515-45G/A515-45S) (Continued)**

CATEGORY	PART DESCRIPTION	ACER PARTNO
	ACETATE TAPE FOR BATTERY(21*21mm)	47.HKKN7.001
	ACETATE TAPE FOR KEYBOARD	47.HNBN7.001
	INS MYLAR FOR LCD PANEL	47.HKCN7.001
<b>Power Cord</b>		
	POWER CORD 1M 125V JAP BLACK	27.NE307.001
	POWER CORD 1M 125V ARG BLACK	27.NE307.004
	POWER CORD 1M 125V AUS BLACK	27.NE307.005
	POWER CORD 1M 125V BRAZIL BLACK	27.NE307.006
	POWER CORD 1M 125V CHINA BLACK	27.NE307.007
	POWER CORD 1M 125V DENMARK BLACK	27.NE307.008
	POWER CORD 1M 125V INDIA BLACK	27.NE307.009
	POWER CORD 1M 125V ISRAEL BLACK	27.NE307.010
	POWER CORD 1M 125V ITL BLACK	27.NE307.011
	POWER CORD 1M 125V S.AFRICA BLACK	27.NE307.012
	POWER CORD 1M 125V SWISS BLACK	27.NE307.013
	POWER CORD 1M 125V EUR+KOR BLACK	27.NE307.015
	POWER CORD 1M 125V US BLACK	27.NE307.003
	POWER CORD 1M 125V UK BLACK	27.NE307.014
POWER CORD 1M 125V TAIWAN BLACK	27.NE307.002	



**Table 6-7. FRU List (A515-46)**

Category	Part Description	Acer Part No.
<b>Adapter</b>		
	Adapter DELTA 45W 19V 1.1x3.0x7.7 ADP-45FE FD LF Black 45W_3phy	KP.04501.017
	Adapter DELTA 45W_3phy INDIA 19V 1.1x3.0x7.7 Black ADP-45FE FE LF Black Meet CoC Tier2 & IEC 62368	KP.04501.022
	Adapter LITE-ON 45W 19V 1.1x3.0x7.7 PA-1450-26A3 LF Black	KP.04503.011
	Adapter Chicony Power 45W 19V 1.1x3.0x7.7 Black A045R072P LF Black Meet CoC Tier2 & IEC 62368, No acer logo	KP.0450H.013
<b>Battery</b>		
	Battery LGC AP18C Polymer 3S1P LGC 3 cell 4343mAh Main COMMON	KT.0030G.020
	Battery PANASONIC Typ.55Wh 3550mAh 4S1P 248x84.4x5.5(mm) AP19B 15.4V 70W Polymer	KT.00405.010
<b>Board</b>		
	Wireless LAN Intel 802.11ax Bluetooth FM AX200.NGWG.NV WiFi 6 CcP2 M.2 2X2 AX + BT 5.0 2230 No vPro (AX200.NGWG.NV-MM#985927 )	KE.11X0N.003
	USB BOARD	55.HWDN7.001
	TOUCHPAD ASSY BLACK W/BKT, MYLAR SYN NC.24611.05J	56.HW3N7.001
	TOUCHPAD ASSY W/ FINGER PRINT BLACK ELAN NC.24611.061	56.HW7N7.001
	TOUCHPAD ASSY SILVER W/BKT, MYLAR SYN NC.24611.05J	56.HW4N7.001
	TOUCHPAD ASSY W/ FINGER PRINT SILVER ELAN NC.24611.061	56.HW8N7.001
<b>Cable</b>		
	FFC CABLE - USB BOARD	50.HWDN7.001






**Table 6-7. FRU List (A515-46) (Continued)**

Category	Part Description	Acer Part No.
	FFC CABLE - FINGER PRINT TOUCHPAD	50.HWDN7.002
	FFC CABLE FOR TOUCH PAD(145.5MM,8P,3V)	50.HGLN7.001
	FFC CABLE FOR HDD(12P/17P,5V)	50.HGLN7.003
	ANTENNA (MAIN+AUX,NGFF)	50.HGLN7.004
	LCD CABLE	50.HWDN7.003
<b>Camera</b>		
	Camera Tech-Front HD Camera HD Camera TF_OV9734_SP2087L2_AOET_KMM4030 Unified2 (add Mic*2)	KS.0HD0Q.004
	Camera CHICONY HD Camera HD Camera CH_OV9734_RT55846N_AOET_SPK0493 Unified2 (add Mic*2)	KS.0HD06.012
<b>Case/Cover/Bracket Assembly</b>		
	LOWER CASE SILVER	60.HVZN7.001
	LOWER CASE BLACK	60.HW1N7.001


**Table 6-7. FRU List (A515-46) (Continued)**

Category	Part Description	Acer Part No.
	HDD BRACKET	33.HGLN7.001
	LCD COVER ASSY SILVER	60.HFQN7.002
	LCD COVER ASSY BLACK	60.HGLN7.002
	LCD BEZEL (W/HINGE CAP) SILVER	60.HFQN7.003
	LCD BEZEL W/HINGE CAP BLACK	60.HGLN7.003
	HINGE L	33.HGLN7.002
	HINGE R	33.HGLN7.003
<b>Fan Sink/Speaker/Earphone/RTC</b>		
	FAN DC 5V	23.HGLN7.001
		
		


**Table 6-7. FRU List (A515-46) (Continued)**

Category	Part Description	Acer Part No.
	SPEAKER (W-L/R)	23.HGLN7.002
<b>HDD/Hard Disk Drive</b>		
	HDD WD 2.5" 5400rpm 1000GB WD10SPZX-21Z10T0 , 7mmzh 1D , 1TB/P , MN1000S SATA III 128MB LF F/W: 02.01A02	KH.01K08.035
	HDD TOSHIBA 2.5" 5400rpm 1000GB MQ04ABF100 , 1TB/P, acer code SATA III 128MB LF+HF F/W:JU002J	KH.01K04.017
	HDD SEAGATE 2.5" 5400rpm 1000GB ST1000LM035 ,1RK172-192 ,Rosewood 1TB ,7mmzh HDD - SATA III 128MB LF F/W:ADM1	KH.01K01.075
	HDD WD 2.5" 5400rpm 2000GB WD20SPZX-21UA7T0 , 7mmzh 2D , 1TB/P , MN1000M SATA III 128MB LF F/W:01.01A01	KH.02K08.020
	Flash Disk SANDISK SSD NAND 256GB BiCS4 SN530 SDBPNPZ-256G-1114 LF+HF	KN.2560D.017
	Flash Disk SANDISK SSD NAND 512GB BiCS4 SN530 SDBPNPZ-512G-1114 LF+HF	KN.5120D.012
	Flash Disk MICRON SSD NAND 1024GB M.2 2280 2210 MTFDHBA1T0QFD-1AX15ABYY LF+HF	KN.01K04.003
	Flash Disk KINGSTON SSD NAND 128GB OM8PDP3128B-AA1 LF+HF	KN.12807.034
	Flash Disk HYNIX SSD NAND 128GB M.2 2280 BC711 HFM128GD3JX016N LF+	KN.1280G.007
<b>Keyboard Assembly</b>		
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Arabic, White BL NK.I1513.103	6B.HWBN7.001
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black FR/Arabic, White BL NK.I1513.10L	6B.HWBN7.002
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Belgium, White BL NK.I1513.10G	6B.HWBN7.003


**Table 6-7. FRU List (A515-46) (Continued)**

Category	Part Description	Acer Part No.
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Swiss/G, White BL NK.I1513.10X	6B.HWBN7.026
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Traditional Chinese, White BL NK.I1513.104	6B.HWBN7.027
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Thailand, White BL NK.I1513.10A	6B.HWBN7.028
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Turkish, White BL NK.I1513.10Y	6B.HWBN7.029
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black US International, White BL NK.I1513.10B	6B.HWBN7.030
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black UK, White BL NK.I1513.10Z	6B.HWBN7.031
	UPPER CASE ASSY BLACK W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Ukrainian, White BL NK.I1513.108	6B.HWBN7.032
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Arabic NK.I1517.0EQ/NK.I1515.0AK/NK.I1513.111	6B.HW7N7.001
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black FR/Arabic NK.I1517.0F7/NK.I1515.0B2/NK.I1513.11J	6B.HW7N7.002
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Belgium NK.I1517.0F3/NK.I1515.0AY/NK.I1513.11E	6B.HW7N7.003
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Brazilian Portuguese NK.I1517.0F4/NK.I1515.0AZ/NK.I1513.11F	6B.HW7N7.004


**Table 6-7. FRU List (A515-46) (Continued)**

Category	Part Description	Acer Part No.
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Traditional Chinese NK.I1517.0ER/NK.I151S.0AL/NK.I1513.112	6B.HW7N7.027
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Thailand NK.I1517.0EX/NK.I151S.0AS/NK.I1513.118	6B.HW7N7.028
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Turkish NK.I1517.0FK/NK.I151S.0BE/NK.I1513.11W	6B.HW7N7.029
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black US International NK.I1517.0EY/NK.I151S.0AT/NK.I1513.119	6B.HW7N7.030
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black UK NK.I1517.0FL/NK.I151S.0BF/NK.I1513.11X	6B.HW7N7.031
	UPPER CASE ASSY BLACK W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Ukrainian NK.I1517.0EV/NK.I151S.0AQ/NK.I1513.116	6B.HW7N7.032
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Arabic, White BL NK.I1513.103	6B.HWCN7.001
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black FR/Arabic, White BL NK.I1513.10L	6B.HWCN7.002
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Belgium, White BL NK.I1513.10G	6B.HWCN7.003
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Brazilian Portuguese, White BL NK.I1513.10H	6B.HWCN7.004
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black US International w/ Bulgaria, White BL NK.I1513.10E	6B.HWCN7.005









**Table 6-7. FRU List (A515-46) (Continued)**

Category	Part Description	Acer Part No.
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Thailand, White BL NK.I1513.10A	6B.HWCN7.028
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black Turkish, White BL NK.I1513.10Y	6B.HWCN7.029
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black US International, White BL NK.I1513.10B	6B.HWCN7.030
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 101KS Black UK, White BL NK.I1513.10Z	6B.HWCN7.031
	UPPER CASE ASSY SILVER W/ BL Keyboard CHICONY SV05P_A72BWL SV5P Internal 15 Standard 100KS Black Ukrainian, White BL NK.I1513.108	6B.HWCN7.032
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Arabic NK.I1517.0EQ/NK.I1515.0AK/NK.I1513.111	6B.HW8N7.001
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black FR/Arabic NK.I1517.0F7/NK.I1515.0B2/NK.I1513.11J	6B.HW8N7.002
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Belgium NK.I1517.0F3/NK.I1515.0AY/NK.I1513.11E	6B.HW8N7.003
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Brazilian Portuguese NK.I1517.0F4/NK.I1515.0AZ/NK.I1513.11F	6B.HW8N7.004
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black US International w/ Bulgaria NK.I1517.0F1/NK.I1515.0AW/NK.I1513.11C	6B.HW8N7.005
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black US International w/ Canadian French NK.I1517.0F0/NK.I1515.0AV/NK.I1513.11B	6B.HW8N7.006

**Table 6-7. FRU List (A515-46) (Continued)**



Category	Part Description	Acer Part No.
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black Turkish NK.I1517.0FK/NK.I151S.0BE/NK.I1513.11W	6B.HW8N7.029
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black US International NK.I1517.0EY/NK.I151S.0AT/NK.I1513.119	6B.HW8N7.030
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 101KS Black UK NK.I1517.0FL/NK.I151S.0BF/NK.I1513.11X	6B.HW8N7.031
	UPPER CASE ASSY SILVER W/ NBL Keyboard SV05T_A72B SV5T Internal 15 Standard 100KS Black Ukrainian NK.I1517.0EV/NK.I151S.0AQ/NK.I1513.116	6B.HW8N7.032
<b>LCD</b>		
	LED LCD Panel AUO 15.6"W WXGA None Glare B156XTN08.1 LF 220nit 8ms 400:1 (eDP, 3.2mm Max, narrow border)	KL.15605.048
	LED LCD Panel AUO 15.6"W FHD None Glare B156HTN06.1 LF 220nit 8ms 400:1 (eDP, narrow border, 3.2mm max, value)	KL.15605.050
	LED LCD Panel CMI 15.6"W FHD None Glare N156HGA-EA3 LF 220nit 10ms 500:1 (eDP, narrow border, 3.2mm max, value)	KL.1560D.035
	LED LCD Panel BOE 15.6"W FHD None Glare NT156FHM-N61 LF 220nit 10ms 500:1 (eDP, narrow border, 3.2mm max, value)	KL.1560E.015
	LED LCD Panel BOE 15.6"W WXGA None Glare NT156WHM-N44 V8.0 LF 220nit 12ms 400:1 (eDP,3.2mm Max, narrow border)	KL.1560E.014
	LED LCD Panel AUO 15.6"W FHD None Glare B156HAN02.1 H/W:4B LF 250nit 25ms 700:1 (eDP, value IPS, narrow border)	KL.15605.062

**Table 6-7. FRU List (A515-46) (Continued)**

Category	Part Description	Acer Part No.
<b>Mainboard</b>		
		
<b>Memory</b>		
	Memory MICRON SO-DIMM DDRIV 3200 4GB MTA4ATF51264HZ-3G2J1 LF+HF 512*16 Z21C	KN.4GB04.022
	Memory SAMSUNG SO-DIMM DDRIV 3200 8GB M471A1K43DB1-CWE LF+HF 1024*8 1ynm D-die	KN.8GB0B.065
	Memory KINGSTON SO-DIMM DDRIV 3200 16GB ACR32D4S2S8ME-16 LF+HF MI-E	KN.16G07.033
<b>Miscellaneous</b>		
	LCD ADHESIVE TAPE	47.HGLN7.001
	RUBBER FOR MIC	47.HGLN7.002
	CONDUCTIVE TAPE	47.HWDN7.001
	INSULATOR MYLAR FOR CABLE	47.HNBN7.002
	ACETATE TAPE FOR BATTERY(21*21mm)	47.HKKN7.001
	ACETATE TAPE FOR KEYBOARD	47.HNBN7.001








**Table 6-7. FRU List (A515-46) (Continued)**

Category	Part Description	Acer Part No.
	INS MYLAR FOR LCD PANEL	47.HKCN7.001
<b>Power Cord</b>		
	POWER CORD 1M 125V JAP BLACK	27.NE307.001
	POWER CORD 1M 125V ARG BLACK	27.NE307.004
	POWER CORD 1M 125V AUS BLACK	27.NE307.005
	POWER CORD 1M 125V BRAZIL BLACK	27.NE307.006
	POWER CORD 1M 125V CHINA BLACK	27.NE307.007
	POWER CORD 1M 125V DENMARK BLACK	27.NE307.008
	POWER CORD 1M 125V INDIA BLACK	27.NE307.009
	POWER CORD 1M 125V ISRAEL BLACK	27.NE307.010
	POWER CORD 1M 125V ITL BLACK	27.NE307.011
	POWER CORD 1M 125V S.AFRICA BLACK	27.NE307.012
	POWER CORD 1M 125V SWISS BLACK	27.NE307.013
	POWER CORD 1M 125V EUR+KOR BLACK	27.NE307.015
	POWER CORD 1M 125V US BLACK	27.NE307.003
	POWER CORD 1M 125V UK BLACK	27.NE307.014
POWER CORD 1M 125V TAIWAN BLACK	27.NE307.002	

# Screw List

---

Table 6-8. Screw List

Category	Part Description	Acer Part No.
	SCREWM2*2.5-I(BNI)(NYLOK)D7T0.3IRON	86.GE8N7.001
	SCREW M2*2.8-IBNI(NYLOK(D5,T0.5STEEL	86.HG6N7.001
	SCREWM2.5*1.8-I(NINYLOK)D5T3.7STEEL	86.GDEN7.002
	SCREW M2.5*6-I(BNI)(NYLOK)IRON	86.SHXN7.004
	SCREW M3*0.5+3.5I	86.TDY07.003