

FRU List


Table 6-3. FRU list



CATEGORY	Pictures	Acer Description	AcerP N	ODM PN
ADAPTER		Adapter DELTA 45W 19V 1.1x3.0x7.7 ADP-45BW X2K LF Meet IEC 26368/CoC Tier2	KP.04 501.0 26	HQ61 21059 8007
		Adapter Chicony Power 45W 19V 1.1x3.0x7.7 Black W045R035L-AC01 LF CN Black with Acer logo, wall-mounted	KP.04 50H.0 08	HQ60 31296 4007
		Adapter DELTA 45W 19V 1.1x3.0x7.7 ADP-45BW Z2K LF Meet IEC 62368/CoC Tier 2	KP.04 501.0 25	HQ61 21059 7007
		Adapter Chicony Power 45W 19V 1.1x3.0x7.7 Black W045R034L-AC01 LF EU Black with Acer logo, wall-mounted	KP.04 50H.0 07	HQ60 31296 2007
		Adapter DELTA 45W 19V 1.1x3.0x7.7 ADP-45BW Y2K LF Meet IEC 62368/ CoC Tier2	KP.04 501.0 24	HQ61 21059 6007
		Adapter Chicony Power 45W 19V 1.1x3.0x7.7 Black W045R033L-AC01 LF US Black with Acer logo, wall-mounted	KP.04 50H.0 06	HQ60 31296 3007
		Adapter DELTA 45W 19V 1.1x3.0x7.7 Black ADP-45FE FD LF Black 45W_3phy,meet CoC Tier-2, IEC-62368	KP.04 501.0 17	HQ60 31338 0007
		Adapter LITE-ON 45W 19V 1.1x3.0x7.7 Black PA-1450-26A3 LF Black	KP.04 503.0 11	HQ60 31359 7007
		Adapter Chicony Power 45W 19V 1.1x3.0x7.7 Black A045R072P LF Black Meet CoC Tier2 & IEC 62368, No acer logo	KP.04 50H.0 13	HQ60 31359 4007
BATTERY		Battery MURATA Typ.48Wh 4200mAh 3S1P AP18C4K 248x84.4x5.5(mm) AP18C 11.4V 60W Polymer	KT.00 304.0 12	HQ60 33520 6007
		Battery LGC Typ.50Wh 4470mAh 3S1P AP18C8K 248x84.4x5.5(mm) AP18C 11.25V 65W Polymer	KT.00 30G.0 20	HQ60 33520 7007
		Battery PANASONIC Typ.55Wh 3550mAh 4S1P AP19B5L 248x84.4x5.5(mm) AP19B 15.4V 70W Polymer	KT.00 405.0 10	HQ61 23014 2007
		Battery LGC Typ.56Wh 4820mAh 3S1P AP19B8M 248x84.4x5.5(mm) AP19B 11.61V Polymer	KT.00 30G.0 24	HQ61 23015 8007
		Battery SIMPLO Typ.56Wh 3634mAh 4S1P AP18C7M 248x84.4x5.5(mm) AP18C 15.4V 60W Polymer	KT.00 407.0 08	HQ60 33527 2007


POWER
CORD





POWER CORD 1M BLACK UK	27.LD RN8.0 01	HQ60 3B000 6000
POWER CORD 1M BLACK EU	27.H3 ZN8.0 01	HQ60 3B000 3000
POWER CORD 1M BLACK US	27.H3 ZN8.0 02	HQ60 3B000 4000
POWER CORD 1M BLACK CN	27.H3 ZN8.0 03	HQ60 3B000 2000
POWER CORD 1M BLACK AUS	27.GR MN8.0 01	HQ60 3B000 7000
POWER CORD 1M BLACK SWISS	27.GR MN8.0 02	HQ60 3B000 9000
POWER CORD 1M BLACK INDIA	27.GR MN8.0 03	HQ60 3B001 0000
POWER CORD 1M BLACK AFRICA	27.H0 UN8.0 02	HQ60 3B003 1000
POWER CORD 1M BLACK TAIWAN (BSMI)	27.HE 3N8.0 01	HQ60 3B003 6000
POWER CORD 1M BLACK TAIWAN (BSMI)	27.HE 3N8.0 01	HQ61 28000 4000
POWER CORD 1M BLACK JAPAN	27.HG 9N8.0 01	HQ60 3B002 3000
POWER CORD 1M BLACK JAPAN	27.HG 9N8.0 01	HQ61 28002 2000
POWER CORD 1M BLACK ISRAEL	27.HG 9N8.0 02	HQ61 28002 0000
POWER CORD 1M BLACK ISRAEL	27.HG 9N8.0 02	HQ60 3B003 3000
POWER CORD 1M BLACK ITALIAN	27.H0 UN8.0 01	HQ60 3B003 0000
POWER CORD 1M BLACK BRAZIL	27.HE 3N8.0 03	HQ61 28002 1000
POWER CORD 1M BLACK ARGENTINA	27.HE 3N8.0 02	HQ61 28000 1000
POWER CORD 1M BLACK KOREAN	27.H0 UN8.0 03	HQ61 28000 2000

CABLE		FFC CABLE TOUCHPAD TO MB 8PIN	50.A3 FN8.0 01	HQ22 02064 7000
		FFC CABLE TOUCHPAD TO MB 8PIN	50.A3 FN8.0 01	HQ22 02064 2000
CABLE		FFC CABLE FINGER PRINT TO MB 6PIN	50.A3 FN8.0 02	HQ22 02064 3000
		FFC CABLE FINGER PRINT TO MB 6PIN	50.A3 FN8.0 02	HQ22 02064 4000
CABLE		FFC CABLE USB TO MB 50PIN	50.A3 FN8.0 03	HQ22 02064 5000
		FFC CABLE USB TO MB 50PIN	50.A3 FN8.0 03	HQ22 02064 6000
CABLE		ANTENNA CABLE MAIN WNC BLACK	50.A3 FN8.0 04	HQ20 60430 7007
CABLE		ANTENNA CABLE AUX WNC GRAY	50.A3 FN8.0 05	HQ20 60430 6007
WiFi Module		Wireless LAN Intel 802.11ax Bluetooth FM AX201.NGWG.NVW WiFi 6 AX 2x2 HrP2 M.2+BT 5.0 2230 No vPro NewOTP SKU	KE.11 X0N.0 14	HQ23 71005 0007
BOARD		USB BOARD ASSY	55.A3 FN8.0 01	HQ31 60AT 82000
POINT DEVICE		TOUCHPAD MODULE CP4WIP3M W/MYLR/SUPPORT SYN (SILVER)	56.HY RN8.0 01	HQ31 60AT 83007

		TOUCHPAD MODULE CP4WIP3M W/MYLR/BRACKET ELAN (SILVER)	56.HY RN8.0 02	HQ31 60AT 84007
		TOUCHPAD MODULE CP4WIP3M W/MYLR/SUPPORT SYN (BLUE)	56.A3 EN8.0 01	HQ31 60AT 85007
		TOUCHPAD MODULE CP4WIP3M W/MYLR/BRACKET ELAN (BLUE)	56.A3 EN8.0 02	HQ31 60AT 86007
		TOUCHPAD MODULE CP4WIP3M W/MYLR/SUPPORT SYN (GOLD)	56.HY MN8.0 01	HQ31 60AT 87007
		TOUCHPAD MODULE CP4WIP3M W/MYLR/BRACKET ELAN (GOLD)	56.HY MN8.0 02	HQ31 60AT 88007
		TOUCHPAD MODULE CP4WIP3M W/MYLR/SUPPORT SYN (PINK)	56.A9 NN8.0 01	HQ31 60BB 42007
		TOUCHPAD MODULE CP4WIP3M W/MYLR/BRACKET ELAN (PINK)	56.A9 NN8.0 02	HQ31 60BB 43007
Finger Print		FINGER PRINT MODULE Egis. ETU811J module 3.3V - Black	NC.22 011.0 0Z	HQ23 60104 1007
CASE/COVER/BRACKET ASSEMBLY		FINGER PRINT BRACKET	33.A3 FN8.0 03	HQ20 90104 2000
CASE/COVER/BRACKET ASSEMBLY		LCD COVER ASSY FOR T3.0MM W/PANEL ADHESIVE (SILVER)	60.HY RN8.0 01	HQ20 70553 2000
		LCD COVER ASSY FOR T3.0MM W/PANEL ADHESIVE (SILVER)	60.HY RN8.0 01	HQ20 70552 7000
		LCD COVER ASSY FOR T3.0MM W/PANEL ADHESIVE (BLUE)	60.A3 EN8.0 01	HQ20 70552 8000
		LCD COVER ASSY FOR T3.0MM W/PANEL ADHESIVE (BLUE)	60.A3 EN8.0 01	HQ20 70552 9000
		LCD COVER ASSY FOR T3.0MM W/PANEL ADHESIVE (GOLD)	60.HY MN8.0 01	HQ20 70540 4000
		LCD COVER ASSY FOR T3.0MM W/PANEL ADHESIVE (GOLD)	60.HY MN8.0 01	HQ20 70547 6000
		LCD COVER ASSY FOR T3.0MM W/PANEL ADHESIVE (PINK)	60.A9 NN8.0 01	HQ20 70576 5000

		LCD COVER ASSY FOR T3.0MM W/PANEL ADHESIVE (IRIDESCENT SILVER)	60.A3 JN8.0 01	HQ20 70553 0000
		LCD COVER ASSY FOR T3.0MM W/PANEL ADHESIVE (IRIDESCENT SILVER)	60.A3 JN8.0 01	HQ20 70553 1000
CASE/COVER/BRACKET ASSEMBLY		LCD COVER ASSY FOR T2.4MM W/PANEL ADHESIVE (SILVER)	60.HY RN8.0 02	HQ20 70541 1000
		LCD COVER ASSY FOR T2.4MM W/PANEL ADHESIVE (SILVER)	60.HY RN8.0 02	HQ20 70553 5000
		LCD COVER ASSY FOR T2.4MM W/PANEL ADHESIVE (BLUE)	60.A3 EN8.0 02	HQ20 70553 3000
		LCD COVER ASSY FOR T2.4MM W/PANEL ADHESIVE (BLUE)	60.A3 EN8.0 02	HQ20 70553 4000
		LCD COVER ASSY FOR T2.4MM W/PANEL ADHESIVE (GOLD)	60.HY MN8.0 02	HQ20 70541 0000
		LCD COVER ASSY FOR T2.4MM W/PANEL ADHESIVE (GOLD)	60.HY MN8.0 02	HQ20 70553 6000
		LCD COVER ASSY FOR T2.4MM W/PANEL ADHESIVE (PINK)	60.A9 NN8.0 02	HQ20 70576 4000
		LCD COVER ASSY FOR T2.4MM W/PANEL ADHESIVE (IRIDESCENT SILVER)	60.A3 JN8.0 02	HQ20 70553 7000
		LCD COVER ASSY FOR T2.4MM W/PANEL ADHESIVE (IRIDESCENT SILVER)	60.A3 JN8.0 02	HQ20 70553 8000
MISCELLANEOUS		LCD PANEL ADHESIVE TAPE_180 mm*8 mm*0.4 mm	47.HY PN8.0 01	HQ22 21209 6000
CASE/COVER/BRACKET ASSEMBLY		LCD BEZEL ASSY (SILVER)	60.HY RN8.0 03	HQ20 71490 3000
		LCD BEZEL ASSY (BLUE)	60.A3 EN8.0 03	HQ20 71506 0000
		LCD BEZEL ASSY (GOLD)	60.HY MN8.0 03	HQ20 71488 9000
		LCD BEZEL ASSY (PINK)	60.A9 NN8.0 03	HQ20 71522 1000
CASE/COVER/BRACKET		HINGE ASSY - L	33.A3 FN8.0 01	HQ22 53009 6000

ASSEMBLY		HINGE ASSY - L	33.A3 FN8.0 01	HQ22 53009 3000
CASE/COVER/BRACKET ASSEMBLY		HINGE ASSY - R	33.A3 FN8.0 02	HQ22 53009 8000
		HINGE ASSY - R	33.A3 FN8.0 02	HQ22 53009 2000
CABLE		LCD EDP CABLE ASSY 40PIN	50.A3 FN8.0 06	HQ21 31052 2000
		LCD EDP CABLE ASSY 40PIN	50.A3 FN8.0 06	HQ21 31052 3000
LCD PANEL		LED LCD Panel CMI 14' FHD None Glare N140HCA-EAC rev C2 LF 250nit 25ms 700:1 (eDP, Value IPS, narrow border, 3.0mm Max)	KL.14 00D.0 27	HQ20 10667 1007
		LED LCD Panel AUO 14' FHD None Glare B140HAN04.0 LF 250nit 25ms 700:1 (eDP, Value IPS, Narrow border, 3.0mm Max)	KL.14 005.0 39	HQ20 10666 7007
		LED LCD Panel CMI 14' FHD None Glare N140HCE-EN2 LF 300nit 25ms 700:1 (eDP, IPS, narrow border, 2.4mm Max)	KL.14 00D.0 24	HQ20 10669 1007
Camera Module		Camera CHICONY HD Camera CH_GC1009_RTS5846N_Powertip_ZTS6735_Windows Y3.2mm (dual Mic distance 66mm)	KS.0H D06.0 19	HQ20 20757 3007
		Camera Tech-Front HD Camera TF_OV9734_SPCA2087N_AOET_ZTS6735_Windows Y3.2mm (dual Mic distance 66mm)	KS.0H D0Q.0 09	HQ20 20757 2007
MISCELLANEOUS		CAMERA RUBBER L BLACK	47.A3 FN8.0 01	HQ22 29019 7000
MISCELLANEOUS		CAMERA RUBBER R BLACK	47.A3 FN8.0 02	HQ22 29019 6000
CASE/COVER/BRACKET		LOWER CASE ASSY SF114 (SILVER)	60.HY SN8.0	HQ20 73071

ET ASSEMBLY			01	8000
		LOWER CASE ASSY SF114 (BLUE)	60.A3 FN8.0 01	HQ20 73072 0000
		LOWER CASE ASSY SF114 (GOLD)	60.HY NN8.0 01	HQ20 73071 9000
		LOWER CASE ASSY SF114 (PINK)	60.A9 NN8.0 04	HQ20 73076 0000
KB ASSEMBLY		UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black US International acer legend, power icon, White BL Meida V0 NK.I1313.0VQ	6B.A7 7N8.0 01	HQ31 60BH 74007
		UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Arabic acer legend, power icon, White BL Meida V0 NK.I1313.0VG	6B.A7 7N8.0 02	HQ31 60BH 77007
		UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Traditional Chinese acer legend, power icon, White BL Meida V0 NK.I1313.0VH	6B.A7 7N8.0 03	HQ31 60BH 78007
		UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Greek acer legend, power icon, White BL Meida V0 NK.I1313.0VJ	6B.A7 7N8.0 04	HQ31 60BH 79007
		UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Korean acer legend, power icon, White BL Meida V0 NK.I1313.0VK	6B.A7 7N8.0 05	HQ31 60BH 80007
		UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Russian acer legend, power icon, White BL Meida V0 NK.I1313.0VL	6B.A7 7N8.0 06	HQ31 60BH 81007
		UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Thailand acer legend, power icon, White BL Meida V0 NK.I1313.0VP	6B.A7 7N8.0 07	HQ31 60BH 82007
		UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black US International w/ Hebrew acer legend, power icon, White BL Meida V0 NK.I1313.0VR	6B.A7 7N8.0 08	HQ31 60BH 75007
		UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Ukrainian acer legend, power icon, White BL Meida V0 NK.I1313.0VM	6B.A7 7N8.0 09	HQ31 60BH 76007
		UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Persian acer legend, power icon, White BL Meida V0 NK.I1313.0VN	6B.A7 7N8.0 10	HQ31 60BH 90007
		UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black US International w/ Bulgaria acer legend, power icon, White BL Meida V0 NK.I1313.0VT	6B.A7 7N8.0 11	HQ31 60BH 91007
		UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black US International w/ Canadian French acer	6B.A7 7N8.0 12	HQ31 60BH 92007

	legend, power icon, White BL Meida V0 NK.I1313.0VS		
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black ALA-Spanish acer legend, power icon, White BL Meida V0 NK.I1313.0VU	6B.A7 7N8.0 13	HQ31 60BH 93007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Belgium acer legend, power icon, White BL Meida V0 NK.I1313.0VV	6B.A7 7N8.0 14	HQ31 60BH 83007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Brazilian Portuguese acer legend, power icon, White BL Meida V0 NK.I1313.0VW	6B.A7 7N8.0 15	HQ31 60BH 84007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black CZ/SK acer legend, power icon, White BL Meida V0 NK.I1313.0VX	6B.A7 7N8.0 16	HQ31 60BH 85007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Danish acer legend, power icon, White BL Meida V0 NK.I1313.0VY	6B.A7 7N8.0 17	HQ31 60BH 86007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black FR/Arabic acer legend, power icon, White BL Meida V0 NK.I1313.0VZ	6B.A7 7N8.0 18	HQ31 60BH 87007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black French acer legend, power icon, White BL Meida V0 NK.I1313.0W0	6B.A7 7N8.0 19	HQ31 60BH 88007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black German acer legend, power icon, White BL Meida V0 NK.I1313.0W1	6B.A7 7N8.0 20	HQ31 60BH 89007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Hungarian acer legend, power icon, White BL Meida V0 NK.I1313.0W2	6B.A7 7N8.0 21	HQ31 60BJ0 1007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Italian acer legend, power icon, White BL Meida V0 NK.I1313.0W3	6B.A7 7N8.0 22	HQ31 60BJ0 2007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Nordic acer legend, power icon, White BL Meida V0 NK.I1313.0W4	6B.A7 7N8.0 23	HQ31 60BJ0 3007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Norwegian acer legend, power icon, White BL Meida V0 NK.I1313.0W5	6B.A7 7N8.0 24	HQ31 60BJ0 4007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Portuguese acer legend, power icon, White BL Meida V0 NK.I1313.0W6	6B.A7 7N8.0 25	HQ31 60BJ0 5007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black SLO/CRO acer legend, power icon, White BL Meida V0 NK.I1313.0W7	6B.A7 7N8.0 26	HQ31 60BJ0 6007

	UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Spanish acer legend, power icon, White BL Meida V0 NK.I1313.0W8	6B.A7 7N8.0 27	HQ31 60BH 94007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Sweden acer legend, power icon, White BL Meida V0 NK.I1313.0W9	6B.A7 7N8.0 28	HQ31 60BH 95007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Swiss/G acer legend, power icon, White BL Meida V0 NK.I1313.0WA	6B.A7 7N8.0 29	HQ31 60BH 96007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Turkish acer legend, power icon, White BL Meida V0 NK.I1313.0WB	6B.A7 7N8.0 30	HQ31 60BH 97007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black UK acer legend, power icon, White BL Meida V0 NK.I1313.0WC	6B.A7 7N8.0 31	HQ31 60BH 98007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 87KS Black Japanese acer legend, power icon, White BL Meida V0 NK.I1313.0WD	6B.A7 7N8.0 32	HQ31 60BH 99007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black US International acer legend, power icon, White BL Meida V0 NK.I1313.0VQ	6B.A7 KN8.0 01	HQ31 60BJ0 0007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Arabic acer legend, power icon, White BL Meida V0 NK.I1313.0VG	6B.A7 KN8.0 02	HQ31 60BJ1 8007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Traditional Chinese acer legend, power icon, White BL Meida V0 NK.I1313.0VH	6B.A7 KN8.0 03	HQ31 60BJ1 9007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Greek acer legend, power icon, White BL Meida V0 NK.I1313.0VJ	6B.A7 KN8.0 04	HQ31 60BJ2 0007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Korean acer legend, power icon, White BL Meida V0 NK.I1313.0VK	6B.A7 KN8.0 05	HQ31 60BJ2 1007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Russian acer legend, power icon, White BL Meida V0 NK.I1313.0VL	6B.A7 KN8.0 06	HQ31 60BJ2 2007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Thailand acer legend, power icon, White BL Meida V0 NK.I1313.0VP	6B.A7 KN8.0 07	HQ31 60BJ2 3007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black US International w/ Hebrew acer legend, power icon, White BL Meida V0 NK.I1313.0VR	6B.A7 KN8.0 08	HQ31 60BJ0 7007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard	6B.A7	HQ31

	CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Ukrainian acer legend, power icon, White BL Meida V0 NK.I1313.0VM	KN8.0 09	60BJ0 8007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Persian acer legend, power icon, White BL Meida V0 NK.I1313.0VN	6B.A7 KN8.0 10	HQ31 60BJ0 9007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black US International w/ Bulgaria acer legend, power icon, White BL Meida V0 NK.I1313.0VT	6B.A7 KN8.0 11	HQ31 60BJ1 0007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black US International w/ Canadian French acer legend, power icon, White BL Meida V0 NK.I1313.0VS	6B.A7 KN8.0 12	HQ31 60BJ1 1007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black ALA-Spanish acer legend, power icon, White BL Meida V0 NK.I1313.0VU	6B.A7 KN8.0 13	HQ31 60BJ1 2007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Belgium acer legend, power icon, White BL Meida V0 NK.I1313.0VV	6B.A7 KN8.0 14	HQ31 60BJ2 4007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Brazilian Portuguese acer legend, power icon, White BL Meida V0 NK.I1313.0VW	6B.A7 KN8.0 15	HQ31 60BJ1 3007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black CZ/SK acer legend, power icon, White BL Meida V0 NK.I1313.0VX	6B.A7 KN8.0 16	HQ31 60BJ1 4007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Danish acer legend, power icon, White BL Meida V0 NK.I1313.0VY	6B.A7 KN8.0 17	HQ31 60BJ1 5007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black FR/Arabic acer legend, power icon, White BL Meida V0 NK.I1313.0VZ	6B.A7 KN8.0 18	HQ31 60BJ1 6007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black French acer legend, power icon, White BL Meida V0 NK.I1313.0W0	6B.A7 KN8.0 19	HQ31 60BJ1 7007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black German acer legend, power icon, White BL Meida V0 NK.I1313.0W1	6B.A7 KN8.0 20	HQ31 60BJ3 0007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Hungarian acer legend, power icon, White BL Meida V0 NK.I1313.0W2	6B.A7 KN8.0 21	HQ31 60BJ3 1007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Italian acer legend, power icon, White BL Meida V0 NK.I1313.0W3	6B.A7 KN8.0 22	HQ31 60BJ3 2007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard	6B.A7 KN8.0	HQ31 60BJ3

	84KS Black Nordic acer legend, power icon, White BL Meida V0 NK.I1313.0W4	23	3007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Norwegian acer legend, power icon, White BL Meida V0 NK.I1313.0W5	6B.A7 KN8.0 24	HQ31 60BJ2 5007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Portuguese acer legend, power icon, White BL Meida V0 NK.I1313.0W6	6B.A7 KN8.0 25	HQ31 60BJ3 4007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black SLO/CRO acer legend, power icon, White BL Meida V0 NK.I1313.0W7	6B.A7 KN8.0 26	HQ31 60BJ3 5007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Spanish acer legend, power icon, White BL Meida V0 NK.I1313.0W8	6B.A7 KN8.0 27	HQ31 60BJ3 6007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Sweden acer legend, power icon, White BL Meida V0 NK.I1313.0W9	6B.A7 KN8.0 28	HQ31 60BJ3 7007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Swiss/G acer legend, power icon, White BL Meida V0 NK.I1313.0WA	6B.A7 KN8.0 29	HQ31 60BJ3 8007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Turkish acer legend, power icon, White BL Meida V0 NK.I1313.0WB	6B.A7 KN8.0 30	HQ31 60BJ2 6007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black UK acer legend, power icon, White BL Meida V0 NK.I1313.0WC	6B.A7 KN8.0 31	HQ31 60BJ2 7007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 87KS Black Japanese acer legend, power icon, White BL Meida V0 NK.I1313.0WD	6B.A7 KN8.0 32	HQ31 60BJ3 9007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black US International acer legend, power icon, White BL Meida V0 NK.I1313.0VQ	6B.A7 BN8.0 01	HQ31 60BJ4 0007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Arabic acer legend, power icon, White BL Meida V0 NK.I1313.0VG	6B.A7 BN8.0 02	HQ31 60BJ2 8007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Traditional Chinese acer legend, power icon, White BL Meida V0 NK.I1313.0VH	6B.A7 BN8.0 03	HQ31 60BJ2 9007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Greek acer legend, power icon, White BL Meida V0 NK.I1313.0VJ	6B.A7 BN8.0 04	HQ31 60BJ4 8007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Korean acer legend, power icon, White BL	6B.A7 BN8.0 05	HQ31 60BJ4 9007

	Meida V0 NK.I1313.0VK		
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Russian acer legend, power icon, White BL Meida V0 NK.I1313.0VL	6B.A7 BN8.0 06	HQ31 60BJ4 1007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Thailand acer legend, power icon, White BL Meida V0 NK.I1313.0VP	6B.A7 BN8.0 07	HQ31 60BJ5 0007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black US International w/ Hebrew acer legend, power icon, White BL Meida V0 NK.I1313.0VR	6B.A7 BN8.0 08	HQ31 60BJ4 2007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Ukrainian acer legend, power icon, White BL Meida V0 NK.I1313.0VM	6B.A7 BN8.0 09	HQ31 60BJ4 3007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Persian acer legend, power icon, White BL Meida V0 NK.I1313.0VN	6B.A7 BN8.0 10	HQ31 60BJ4 4007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black US International w/ Bulgaria acer legend, power icon, White BL Meida V0 NK.I1313.0VT	6B.A7 BN8.0 11	HQ31 60BJ4 5007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black US International w/ Canadian French acer legend, power icon, White BL Meida V0 NK.I1313.0VS	6B.A7 BN8.0 12	HQ31 60BJ4 6007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black ALA-Spanish acer legend, power icon, White BL Meida V0 NK.I1313.0VU	6B.A7 BN8.0 13	HQ31 60BJ4 7007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Belgium acer legend, power icon, White BL Meida V0 NK.I1313.0VV	6B.A7 BN8.0 14	HQ31 60BJ5 1007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Brazilian Portuguese acer legend, power icon, White BL Meida V0 NK.I1313.0VW	6B.A7 BN8.0 15	HQ31 60BJ5 2007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black CZ/SK acer legend, power icon, White BL Meida V0 NK.I1313.0VX	6B.A7 BN8.0 16	HQ31 60BJ5 3007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Danish acer legend, power icon, White BL Meida V0 NK.I1313.0VY	6B.A7 BN8.0 17	HQ31 60BJ5 4007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black FR/Arabic acer legend, power icon, White BL Meida V0 NK.I1313.0VZ	6B.A7 BN8.0 18	HQ31 60BJ5 5007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black French acer legend, power icon, White BL Meida V0 NK.I1313.0W0	6B.A7 BN8.0 19	HQ31 60BJ5 6007

	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black German acer legend, power icon, White BL Meida V0 NK.I1313.0W1	6B.A7 BN8.0 20	HQ31 60BJ5 7007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Hungarian acer legend, power icon, White BL Meida V0 NK.I1313.0W2	6B.A7 BN8.0 21	HQ31 60BJ5 8007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Italian acer legend, power icon, White BL Meida V0 NK.I1313.0W3	6B.A7 BN8.0 22	HQ31 60BJ5 9007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Nordic acer legend, power icon, White BL Meida V0 NK.I1313.0W4	6B.A7 BN8.0 23	HQ31 60BJ6 0007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Norwegian acer legend, power icon, White BL Meida V0 NK.I1313.0W5	6B.A7 BN8.0 24	HQ31 60BJ6 1007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Portuguese acer legend, power icon, White BL Meida V0 NK.I1313.0W6	6B.A7 BN8.0 25	HQ31 60BJ6 2007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black SLO/CRO acer legend, power icon, White BL Meida V0 NK.I1313.0W7	6B.A7 BN8.0 26	HQ31 60BJ6 3007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Spanish acer legend, power icon, White BL Meida V0 NK.I1313.0W8	6B.A7 BN8.0 27	HQ31 60BJ6 4007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Sweden acer legend, power icon, White BL Meida V0 NK.I1313.0W9	6B.A7 BN8.0 28	HQ31 60BJ6 5007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Swiss/G acer legend, power icon, White BL Meida V0 NK.I1313.0WA	6B.A7 BN8.0 29	HQ31 60BJ6 6007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Turkish acer legend, power icon, White BL Meida V0 NK.I1313.0WB	6B.A7 BN8.0 30	HQ31 60BJ6 7007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black UK acer legend, power icon, White BL Meida V0 NK.I1313.0WC	6B.A7 BN8.0 31	HQ31 60BJ6 8007
	UPPER CASE ASSY SF114-34 (GOLD) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 87KS Black Japanese acer legend, power icon, White BL Meida V0 NK.I1313.0WD	6B.A7 BN8.0 32	HQ31 60BJ6 9007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black US International acer legend, power icon, White BL Meida V0 NK.I1313.0VQ	6B.A9 UN8.0 01	HQ31 60BK 28007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard	6B.A9	HQ31

	CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Arabic acer legend, power icon, White BL Meida V0 NK.I1313.0VG	UN8.0 02	60BK 30007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Traditional Chinese acer legend, power icon, White BL Meida V0 NK.I1313.0VH	6B.A9 UN8.0 03	HQ31 60BK 29007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Greek acer legend, power icon, White BL Meida V0 NK.I1313.0VJ	6B.A9 UN8.0 04	HQ31 60BK 31007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Korean acer legend, power icon, White BL Meida V0 NK.I1313.0VK	6B.A9 UN8.0 05	HQ31 60BK 32007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Russian acer legend, power icon, White BL Meida V0 NK.I1313.0VL	6B.A9 UN8.0 06	HQ31 60BK 33007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Thailand acer legend, power icon, White BL Meida V0 NK.I1313.0VP	6B.A9 UN8.0 07	HQ31 60BK 34007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black US International w/ Hebrew acer legend, power icon, White BL Meida V0 NK.I1313.0VR	6B.A9 UN8.0 08	HQ31 60BK 35007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Ukrainian acer legend, power icon, White BL Meida V0 NK.I1313.0VM	6B.A9 UN8.0 09	HQ31 60BK 36007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black Persian acer legend, power icon, White BL Meida V0 NK.I1313.0VN	6B.A9 UN8.0 10	HQ31 60BK 37007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black US International w/ Bulgaria acer legend, power icon, White BL Meida V0 NK.I1313.0VT	6B.A9 UN8.0 11	HQ31 60BK 38007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 83KS Black US International w/ Canadian French acer legend, power icon, White BL Meida V0 NK.I1313.0VS	6B.A9 UN8.0 12	HQ31 60BK 39007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black ALA-Spanish acer legend, power icon, White BL Meida V0 NK.I1313.0VU	6B.A9 UN8.0 13	HQ31 60BK 40007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Belgium acer legend, power icon, White BL Meida V0 NK.I1313.0VV	6B.A9 UN8.0 14	HQ31 60BK 41007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Brazilian Portuguese acer legend, power icon, White BL Meida V0 NK.I1313.0VW	6B.A9 UN8.0 15	HQ31 60BK 42007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard	6B.A9 UN8.0	HQ31 60BK

	84KS Black CZ/SK acer legend, power icon, White BL Meida V0 NK.I1313.0VX	16	43007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Danish acer legend, power icon, White BL Meida V0 NK.I1313.0VY	6B.A9 UN8.0 17	HQ31 60BK 44007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black FR/Arabic acer legend, power icon, White BL Meida V0 NK.I1313.0VZ	6B.A9 UN8.0 18	HQ31 60BK 45007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black French acer legend, power icon, White BL Meida V0 NK.I1313.0W0	6B.A9 UN8.0 19	HQ31 60BK 46007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black German acer legend, power icon, White BL Meida V0 NK.I1313.0W1	6B.A9 UN8.0 20	HQ31 60BK 47007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Hungarian acer legend, power icon, White BL Meida V0 NK.I1313.0W2	6B.A9 UN8.0 21	HQ31 60BK 48007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Italian acer legend, power icon, White BL Meida V0 NK.I1313.0W3	6B.A9 UN8.0 22	HQ31 60BK 49007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Nordic acer legend, power icon, White BL Meida V0 NK.I1313.0W4	6B.A9 UN8.0 23	HQ31 60BK 50007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Norwegian acer legend, power icon, White BL Meida V0 NK.I1313.0W5	6B.A9 UN8.0 24	HQ31 60BK 51007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Portuguese acer legend, power icon, White BL Meida V0 NK.I1313.0W6	6B.A9 UN8.0 25	HQ31 60BK 52007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black SLO/CRO acer legend, power icon, White BL Meida V0 NK.I1313.0W7	6B.A9 UN8.0 26	HQ31 60BK 53007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Spanish acer legend, power icon, White BL Meida V0 NK.I1313.0W8	6B.A9 UN8.0 27	HQ31 60BK 54007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Sweden acer legend, power icon, White BL Meida V0 NK.I1313.0W9	6B.A9 UN8.0 28	HQ31 60BK 55007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Swiss/G acer legend, power icon, White BL Meida V0 NK.I1313.0WA	6B.A9 UN8.0 29	HQ31 60BK 56007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black Turkish acer legend, power icon, White BL	6B.A9 UN8.0 30	HQ31 60BK 57007




	Meida V0 NK.I1313.0WB		
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 84KS Black UK acer legend, power icon, White BL Meida V0 NK.I1313.0WC	6B.A9 UN8.0 31	HQ31 60BK 58007
	UPPER CASE ASSY SF114-34 (PINK) Keyboard CHICONY SV03P_A80BWL SV3P Internal 13 Standard 87KS Black Japanese acer legend, power icon, White BL Meida V0 NK.I1313.0WD	6B.A9 UN8.0 32	HQ31 60BK 59007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 83KS Black US International acer legend, power icon, Meida V0	6B.A7 9N8.0 01	HQ31 60BK 60007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 83KS Black Arabic acer legend, power icon, Meida V0	6B.A7 9N8.0 02	HQ31 60BK 61007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 83KS Black Traditional Chinese acer legend, power icon, Meida V0	6B.A7 9N8.0 03	HQ31 60BK 62007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 83KS Black Greek acer legend, power icon, Meida V0	6B.A7 9N8.0 04	HQ31 60BK 63007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 83KS Black Korean acer legend, power icon, Meida V0	6B.A7 9N8.0 05	HQ31 60BK 64007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 83KS Black Russian acer legend, power icon, Meida V0	6B.A7 9N8.0 06	HQ31 60BK 65007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 83KS Black Thailand acer legend, power icon, Meida V0	6B.A7 9N8.0 07	HQ31 60BK 75007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 83KS Black US International w/ Hebrew acer legend, power icon, Meida V0	6B.A7 9N8.0 08	HQ31 60BK 76007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 83KS Black Ukrainian acer legend, power icon, Meida V0	6B.A7 9N8.0 09	HQ31 60BK 77007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 83KS Black Persian acer legend, power icon, Meida V0	6B.A7 9N8.0 10	HQ31 60BK 78007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 83KS Black US International w/ Bulgaria acer legend, power icon, Meida V0	6B.A7 9N8.0 11	HQ31 60BK 79007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 83KS Black US International w/ Canadian French acer legend, power icon, Meida V0	6B.A7 9N8.0 12	HQ31 60BK 80007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black ALA-Spanish acer legend, power icon, Meida V0	6B.A7 9N8.0 13	HQ31 60BK 81007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black Belgium acer legend, power icon, Meida V0	6B.A7 9N8.0 14	HQ31 60BK 82007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black Brazilian Portuguese acer legend, power icon, Meida V0	6B.A7 9N8.0 15	HQ31 60BK 66007





	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black CZ/SK acer legend, power icon, Meida V0	6B.A7 9N8.0 16	HQ31 60BK 67007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black Danish acer legend, power icon, Meida V0	6B.A7 9N8.0 17	HQ31 60BK 68007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black FR/Arabic acer legend, power icon, Meida V0	6B.A7 9N8.0 18	HQ31 60BK 69007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black French acer legend, power icon, Meida V0	6B.A7 9N8.0 19	HQ31 60BK 70007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black German acer legend, power icon, Meida V0	6B.A7 9N8.0 20	HQ31 60BK 71007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black Hungarian acer legend, power icon, Meida V0	6B.A7 9N8.0 21	HQ31 60BK 72007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black Italian acer legend, power icon, Meida V0	6B.A7 9N8.0 22	HQ31 60BK 73007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black Nordic acer legend, power icon, Meida V0	6B.A7 9N8.0 23	HQ31 60BK 74007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black Norwegian acer legend, power icon, Meida V0	6B.A7 9N8.0 24	HQ31 60BK 83007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black Portuguese acer legend, power icon, Meida V0	6B.A7 9N8.0 25	HQ31 60BK 84007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black SLO/CRO acer legend, power icon, Meida V0	6B.A7 9N8.0 26	HQ31 60BK 85007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black Spanish acer legend, power icon, Meida V0	6B.A7 9N8.0 27	HQ31 60BK 86007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black Sweden acer legend, power icon, Meida V0	6B.A7 9N8.0 28	HQ31 60BK 87007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black Swiss/G acer legend, power icon, Meida V0	6B.A7 9N8.0 29	HQ31 60BK 88007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black Turkish acer legend, power icon, Meida V0	6B.A7 9N8.0 30	HQ31 60BK 89007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black UK acer legend, power icon, Meida V0	6B.A7 9N8.0 31	HQ31 60BK 90007
	UPPER CASE ASSY SF114-34 (SILVER) Keyboard SV03T_A80B SV3T Internal 13 Standard 87KS Black Japanese acer legend, power icon, Meida V0	6B.A7 9N8.0 32	HQ31 60BK 91007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 83KS Black US International acer legend, power icon, Meida V0	6B.A7 FN8.0 01	HQ31 60BK 92007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 83KS Black Arabic acer legend, power icon, Meida V0	6B.A7 FN8.0 02	HQ31 60BK 94007

	UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 83KS Black Traditional Chinese acer legend, power icon, Meida V0	6B.A7 FN8.0 03	HQ31 60BK 95007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 83KS Black Greek acer legend, power icon, Meida V0	6B.A7 FN8.0 04	HQ31 60BK 96007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 83KS Black Korean acer legend, power icon, Meida V0	6B.A7 FN8.0 05	HQ31 60BK 97007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 83KS Black Russian acer legend, power icon, Meida V0	6B.A7 FN8.0 06	HQ31 60BK 98007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 83KS Black Thailand acer legend, power icon, Meida V0	6B.A7 FN8.0 07	HQ31 60BK 99007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 83KS Black US International w/ Hebrew acer legend, power icon, Meida V0	6B.A7 FN8.0 08	HQ31 60BL0 0007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 83KS Black Ukrainian acer legend, power icon, Meida V0	6B.A7 FN8.0 09	HQ31 60BL0 1007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 83KS Black Persian acer legend, power icon, Meida V0	6B.A7 FN8.0 10	HQ31 60BL0 2007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 83KS Black US International w/ Bulgaria acer legend, power icon, Meida V0	6B.A7 FN8.0 11	HQ31 60BL0 3007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 83KS Black US International w/ Canadian French acer legend, power icon, Meida V0	6B.A7 FN8.0 12	HQ31 60BL0 4007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black ALA-Spanish acer legend, power icon, Meida V0	6B.A7 FN8.0 13	HQ31 60BL0 5007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black Belgium acer legend, power icon, Meida V0	6B.A7 FN8.0 14	HQ31 60BL0 6007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black Brazilian Portuguese acer legend, power icon, Meida V0	6B.A7 FN8.0 15	HQ31 60BL0 7007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black CZ/SK acer legend, power icon, Meida V0	6B.A7 FN8.0 16	HQ31 60BL0 8007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black Danish acer legend, power icon, Meida V0	6B.A7 FN8.0 17	HQ31 60BL0 9007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black FR/Arabic acer legend, power icon, Meida V0	6B.A7 FN8.0 18	HQ31 60BL1 0007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black French acer legend, power icon, Meida V0	6B.A7 FN8.0 19	HQ31 60BL1 1007
	UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black German acer legend, power icon, Meida V0	6B.A7 FN8.0 20	HQ31 60BL1 2007

		UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black Hungarian acer legend, power icon, Meida V0	6B.A7 FN8.0 21	HQ31 60BL1 3007
		UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black Italian acer legend, power icon, Meida V0	6B.A7 FN8.0 22	HQ31 60BL1 4007
		UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black Nordic acer legend, power icon, Meida V0	6B.A7 FN8.0 23	HQ31 60BK 93007
		UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black Norwegian acer legend, power icon, Meida V0	6B.A7 FN8.0 24	HQ31 60BL1 5007
		UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black Portuguese acer legend, power icon, Meida V0	6B.A7 FN8.0 25	HQ31 60BL1 6007
		UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black SLO/CRO acer legend, power icon, Meida V0	6B.A7 FN8.0 26	HQ31 60BL1 7007
		UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black Spanish acer legend, power icon, Meida V0	6B.A7 FN8.0 27	HQ31 60BL1 8007
		UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black Sweden acer legend, power icon, Meida V0	6B.A7 FN8.0 28	HQ31 60BL1 9007
		UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black Swiss/G acer legend, power icon, Meida V0	6B.A7 FN8.0 29	HQ31 60BL2 0007
		UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black Turkish acer legend, power icon, Meida V0	6B.A7 FN8.0 30	HQ31 60BL2 1007
		UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 84KS Black UK acer legend, power icon, Meida V0	6B.A7 FN8.0 31	HQ31 60BL3 3007
		UPPER CASE ASSY SF114-34 (BLUE) Keyboard SV03T_A80B SV3T Internal 13 Standard 87KS Black Japanese acer legend, power icon, Meida V0	6B.A7 FN8.0 32	HQ31 60BL3 4007
MAINBOARD		Mainboard SF114-34 Intel ICDN4500 4GB UMA W/RTC	NB.A7 F11.0 0B	HQ31 60BG 27000
		Mainboard SF114-34 Intel ICDN4500 8GB UMA W/RTC	NB.A7 F11.0 01	HQ31 60BG 28000
		Mainboard SF114-34 Intel ICDN4500 16GB UMA W/RTC	NB.A7 F11.0 02	HQ31 60BG 29000
		Mainboard SF114-34 Intel ICQN5100 4GB UMA W/RTC	NB.A7 F11.0 0C	HQ31 60BG 36000
		Mainboard SF114-34 Intel ICQN5100 8GB UMA W/RTC	NB.A7 F11.0 03	HQ31 60BG 37000
		Mainboard SF114-34 Intel ICQN5100 16GB UMA W/RTC	NB.A7 F11.0 04	HQ31 60BG 38000
		Mainboard SF114-34 Intel PQCN6000 4GB UMA W/RTC	NB.A7 F11.0 0D	HQ31 60BG 47000

	Mainboard SF114-34 Intel PQC�6000 8GB UMA W/RTC	NB.A7 F11.0 05	HQ31 60BG 45000
	Mainboard SF114-34 Intel PQC�6000 16GB UMA W/RTC	NB.A7 F11.0 06	HQ31 60BG 46000
	Mainboard SF114-34 Intel ICDN4500 4GB eMMC64GB UMA W/RTC	NB.A7 D11.0 0D	HQ31 60BG 30000
	Mainboard SF114-34 Intel ICDN4500 4GB eMMC128GB UMA W/RTC	NB.A7 D11.0 0E	HQ31 60BG 31000
	Mainboard SF114-34 Intel ICDN4500 8GB eMMC64GB UMA W/RTC	NB.A7 D11.0 05	HQ31 60BG 32000
	Mainboard SF114-34 Intel ICDN4500 8GB eMMC128GB UMA W/RTC	NB.A7 D11.0 06	HQ31 60BG 33000
	Mainboard SF114-34 Intel ICDN4500 16GB eMMC64GB UMA W/RTC	NB.A7 D11.0 07	HQ31 60BG 34000
	Mainboard SF114-34 Intel ICDN4500 16GB eMMC128GB UMA W/RTC	NB.A7 D11.0 08	HQ31 60BG 35000
	Mainboard SF114-34 Intel ICQN5100 4GB eMMC64GB UMA W/RTC	NB.A7 D11.0 0F	HQ31 60BG 39000
	Mainboard SF114-34 Intel ICQN5100 4GB eMMC128GB UMA W/RTC	NB.A7 D11.0 0G	HQ31 60BG 40000
	Mainboard SF114-34 Intel ICQN5100 8GB eMMC64GB UMA W/RTC	NB.A7 D11.0 09	HQ31 60BG 42000
	Mainboard SF114-34 Intel ICQN5100 8GB eMMC128GB UMA W/RTC	NB.A7 D11.0 0A	HQ31 60BG 41000
	Mainboard SF114-34 Intel ICQN5100 16GB eMMC64GB UMA W/RTC	NB.A7 D11.0 0B	HQ31 60BG 43000
	Mainboard SF114-34 Intel ICQN5100 16GB eMMC128GB UMA W/RTC	NB.A7 D11.0 0C	HQ31 60BG 44000
	Mainboard SF114-34 Intel PQC�6000 4GB eMMC64GB UMA W/RTC	NB.A7 D11.0 0H	HQ31 60BG 48000
	Mainboard SF114-34 Intel PQC�6000 4GB eMMC128GB UMA W/RTC	NB.A7 D11.0 0J	HQ31 60BG 49000
	Mainboard SF114-34 Intel PQC�6000 8GB eMMC64GB UMA W/RTC	NB.A7 D11.0 01	HQ31 60BG 50000
	Mainboard SF114-34 Intel PQC�6000 8GB eMMC128GB UMA W/RTC	NB.A7 D11.0 02	HQ31 60BG 51000
	Mainboard SF114-34 Intel PQC�6000 16GB eMMC64GB UMA W/RTC	NB.A7 D11.0 03	HQ31 60BG 52000

		Mainboard SF114-34 Intel PQC6000 16GB eMMC128GB UMA W/RTC	NB.A7 D11.0 04	HQ31 60BG 53000
FAN SINK/SPE AK/EARPH ONE/RTC		THERMAL PLATE W/PASTE	24.A3 FN8.0 01	HQ23 31021 1000
		THERMAL PLATE W/PASTE	24.A3 FN8.0 01	HQ23 31021 0000
FAN SINK/SPE AK/EARPH ONE/RTC		SPEAKER SET (L+R)	23.A3 FN8.0 01	HQ20 33077 1000
		SPEAKER SET (L+R)	23.A3 FN8.0 01	HQ20 33077 0000
HDD		Flash Disk SANDISK SSD NAND 128GB SDAPNUW- 128G-1014 LF+HF	KN.12 80D.0 10	HQ23 73016 1007
		Flash Disk SAMSUNG SSD NAND 128GB M.2 2280 PM991 MZVLQ128HBHQ-00000 LF+HF	KN.12 80B.0 10	HQ23 73027 4007
		Flash Disk SANDISK SSD NAND 256GB BiCS4 SN530 SDBPNPZ-256G-1014 LF+HF	KN.25 60D.0 14	HQ23 73034 6007
		Flash Disk HYNIX SSD NAND 256GB M.2 2280 BC511 HFM256GDJTN1-82A0A LF+HF	KN.25 60G.0 29	HQ23 73026 0007
		Flash Disk HYNIX SSD NAND 512GB M.2 2280 BC511 HFM512GDJTN1-82A0A LF+HF	KN.51 20G.0 33	HQ23 73025 9007
		Flash Disk SANDISK SSD NAND 512GB BiCS4 SN530 SDBPNPZ-512G-1014 LF+HF	KN.51 20D.0 10	HQ23 73034 7007
MISCELLA NEOUS		TOUCHPAD CONDUCTIVE CLOTH_50 MM*35 MM*0.1 MM	47.A3 FN8.0 03	HQ21 94194 3000
		TOUCHPAD CONDUCTIVE CLOTH_50 MM*35 MM*0.1 MM	47.A3 FN8.0 03	HQ21 94195 2000
MISCELLA NEOUS		GOLD MYLAR_35 MM*12 MM*0.1 MM	47.A3 FN8.0 04	HQ22 23216 3000
		GOLD MYLAR_35 MM*12 MM*0.1 MM	47.A3 FN8.0 04	HQ22 23217 3000
MISCELLA NEOUS		ACETATE CLOTH_25 MM*10 MM*0.1 MM	47.A3 FN8.0 05	HQ22 23216 4000

		ACETATE CLOTH_25 MM*10 MM*0.1 MM	47.A3 FN8.0 05	HQ22 23217 4000
MISCELLA NEOUS		TP SPONGE_108*18MM	47.A3 FN8.0 06	HQ22 23216 2000
		TP SPONGE_108*18MM	47.A3 FN8.0 06	HQ22 23217 5000
SCREW		SCREW_M2.0*2.6 MM_0.6 MM_7.5 MM_BLACK_NYLOK	86.A3 FN8.0 01	HQ22 11074 7000
SCREW		SCREW_M2.5*5.6 MM_0.6 MM_5 MM_BLACK_NYLOK	86.A3 FN8.0 02	HQ22 11074 6000
SCREW		SCREW_M2.0*3 MM_0.5 MM_5 MM_SILVER_NYLOK	86.A3 FN8.0 03	HQ22 11074 5000
SCREW		SCREW_M2.0*3.5 MM_0.5 MM_5 MM_BLACK_NYLOK	86.A3 FN8.0 04	HQ22 11074 9000
SCREW		SCREW_M2.0*5.8 MM_0.8 MM_4 MM_SILVER_NYLOK	86.A3 FN8.0 05	HQ22 11075 0000